# Maintenance Manual for Embroidery Machine

# HCH-701P-30

Version 1.1





HappyJapan Inc.

## # For safe adjustment and repair #

In order to conduct adjustment and repair safely and surely, please be sure to abide by what is mentioned in this manual to prevent trouble.

### ⚠

- 1. When you conduct adjustment and repair of this embroidery machine or handle electric related parts, you are required to take technical lesson in advance.
- 2. When you conduct adjustment and repair using this manual, please be sure to use together with instruction with it in hand.
  - # Please conduct in accordance with work process in this manual.
  - # In case there are no specific instructions or explanations in work process.
    - please be sure to unplug cord from receptacle.
  - # When you exchange parts, please be sure to use genuine parts designated by us.
  - # Please never remodel the embroidery machine.

When you handle circuit boards:

- # In order to prevent troubles from static electricity, please remove earth from human body.
- # Please don't touch metal part of circuit board with bare hand as it will short-circuit and threaten to break circuit boards.
- # When you removed circuits boards from the machine or you store or transport them, please wrap them in static electricity preventive bag and avoid to give shock.

## Index

For safe adjustment and repair					
Index					
	Special tool, Measuring equipment, Other	7			
1	Outline of mechanism				
	1-1 Outline of mechanical mechanism				
	1-2 Placement of key electronic parts	12			
2	Outer covers				
	2-1 Removal of outer covers	13			
3	Mechanical mechanism				
	3-1 Basic maintenance				
	3-1-1 Maintenance of thread path				
	3-1-2 Fixing of needle				
	3-1-3 Selection of thread				
	3-1-4 Relation between needle and upper thread	22			
	3-2 Fixed head 3-2-1 Exchange of crank	23			
	3-2-2 Exchange of rod				
	3-2-3 Adjustment of the lowest needle point				
		20			
	3-2-8 Adjustment of take-up lever timing				
	3-2-9 Exchange of pressure foot cam				
	3-2-10 Check of height of pressure foot				
	3-2-11 Exchange of pressure foot				
	3-2-12 Adjustment of height of pressure foot guide bar				
	3-2-13 Exchange of pressure foot link and block				
	3-2-14 Exchange of pressure foot drive lever				
	3-2-15 Exchange of pressure foot guide				
	3-2-16 Exchange of pulse motor for pressure foot				
	3-2-17 Adjustment of pressure foot bracket ass'y	47			

## Index

		page
3-2-1	8 Exchange of thread catcher	48
	1 Adjustment of bobbin winder	
022		
3-3 Mov	<i>v</i> ing head	
3-3-1	Assemble the upper rail of moving head	52
3-3-2	Adjustment of backlash (back and forth) of moving head	53
3-3-3	Assemble the moving head	54
3-3-4	Adjustment of needle position (back and forth)	58
3-3-5	Check of needle position	
3-3-6	Adjustment of needle height	60
3-3-7	Exchange of needle bar and needle bar spring	
3-3-8	Fixing of needle bar boss guide plate	
3-3-9	Exchange of take-up lever	66
3-3-1	0 Exchange of thread adjusting spring	
3-3-1	1 Adjustment of tension of thread adjusting spring	68
3-3-1	2 Adjustment of laser pointer	
3-3-1	3 Adjustment of thread holder	70
3-3-1	4 Exchange of majic-tape on thread holder	
3-4 Nee	dle bar change unit	
	Fixing of needle bar change unit	73
3-5 Rot	ary hook	
3-5-1	Adjustment of rotary hook timing	75
3-5-2	Adjustment of retainer on rotary hook	77
3-6 Thr	ead cut unit	
3-6-1	Assemble the arm ass'y	78
3-6-2	Exchange of pulse motor for thread cutting driver	
3-6-6		
3-6-7	Exchange of fixed knife	
3-6-8	Adjustment of moving knife and fixed knife	
3-6-9		
3-6-1	0 Adjustment of bobbin thread holder	
	1 Exchange of keeper solenoid	
	2 Adjustment of position of keeper	

## Index

		page			
3-7 (2)	rriage unit				
3-7-1	Adjustment of X carriage belt tension				
3-7-2	Exchange of X carriage belt				
-	3-7-2 Exchange of X carriage belt tension				
3-7-4	Exchange of Y carriage belt				
5-7-4		57			
3-8 Tran	smission unit				
3-8-1					
3-8-2	Exchange of timing belt	100			
3-8-3	Adjustment of motor belt tension	102			
3-8-4	Exchange of motor and motor belt	104			
4 Electricity					
4-1 Circu	iit board related parts				
4-1-1	Remove LCD and LCD-CE board	106			
4-1-2	Setting for LCD-CE board				
4-1-3	Setting for power supply	109			
4-2 Sens	sors				
4-2-1					
4-2-2	Adjustment of TC board				
4-2-3	Adjustment of stop position of needle bar change unit	111			
4-3 Inve					
4-3-1	Remove of Inverter				
4-3-2	Inverter Installation				
4-3-3	How to set inverter				
4-3-4	Initialization of parameter	119			
4-4 Init	ialization of system				
4-4-1	Program update procedure				
4-4-2	Preparation for program update				
4-4-3	Machine program and Main program update				
4-4-4	Setting of revolution				
·					
4-5 Ma	intenance mode.				
4-5-1	How to enter maintenance mode				


	4-5-2	Machine Test——Machine movement	125			
	4-5-3 Memory All Clear—Initialization of memory					
	4-5-4	Record — Opereration data display				
		4-5-4-1 Total number of stitch				
		4-5-4-2 Record of Error occurrence	129			
		4-5-4-3 Number of occurrence in each error display	130			
		4-5-4-4 Thread break history	131			
		4-5-4-5 Machine setting	132			
		4-5-4-6 Maintenance Register—Registration of machine maintenance date	133			
		4-5-4-7 Machine Setting Navigation after exchanging CONT board	134			
5	Electrica	I connection diagram	136			
6	Explana	tion of function of circuit board	141			
7	Others					
	7-1 How to respond for some question ( As example step)					
	7-2 Trouble shooting					
	7-2-1 Electricity doesn't turn on					
	7-2-2	Thread break				
	7-2-3	Erraneous thread cut	154			
	7-2-4	<ul> <li>7-2-4 Off-registration of pattern</li> <li>7-2-5 Upper thread comes off from needle hole</li> </ul>				
	7-2-6	Upper thread remains				
	7-2-7	Malfunction of thread break detection	161			
	7-2-8	Suspension of upper shaft	163			
	7-2-9					
	7-2-10 Defect on thread catcher					
	7-2-11	Others (Mechanical)	166			
	7-2-12 Others (Electronically)					
	7-3 Error					
	7-3-1	Startup error and measure	158			
	7-3-2	7-3-2 Error and measure				
	7-4 Reference date					
	7-4-1	Tables for timing / adjustment value	172			
	7-4-2	Use TAJIMA made tubular frame	173			

Page

# Special tool, Measuring equipment, Other

### HSA90020

2.0mm thickness gauge (Page 88, 89)




### HSA90030

Keeper positioning gauge (Page 89)



### HSA90050

Bering positioning gauge [4.85mm] (Page 34)



## Special tool, Measuring equipment, Other

### HSA90080

Retainer positioning gauge [0.8mm] (Page 77)



HSA90090 Positioning pin (Page 35)




HSA90131

1.2mm thickness gauge (Page 37)



HSA90200

0.03mm thickness gauge (Page 27, 66)




HSA90230 Tensile gauge (Page 87)



# Special tool, Measuring equipment, Other

### HSA90240

Dial-gauge set (Page 28)



### HSA90270

Vernier calliper gauge [200mm]




### HSA90280

Tension gauge 1000cN (Page 91, 95, 103)



### HSA90311


Shell alvania EP Grease 100g




### M0404342

Needle height gauge (Page 61)






## Outline of mechanical mechanism




# Placement of key electronic parts




# Removal of outer covers (THREAD STAND)

1. Remove thread guide bracket.



2. Loosen a screw of thread guide pillar




3. Remove thread guide pillar and thread stand.




<Check> Be sure to turn power switch OFF before work.


1. Remove three setscrews of arm E as shown in the figure below.




2. Disconnect the connectors indicated by the arrows in the figure below. Remove the screw that fixes cables.



3. Remove three setscrews on arm G as shown in the figure below.



4. Remove control box.



Please reverse procedure when installing control box.


5. Disconnect cable for X carriage.



8. Take off rubber cap.




6. Remove 2 screws, then take the X carriage off.



7. Remove the guide.




9. Remove cover (left). (Remove screw in arrow mark)




 Unlock nail of the cover (left) by pressing an arrow point of the cover (right).



- 11. Remove the cover by pressing an arrow part of the picture.
  - (1) Upper part of the cover



(2) Front part of the cover





- Nail shape
- Male nail shape






12. Remove the screw of an arrow part of the picture which fixes cover (right).







13. Remove an arrow marked screw which fixes hold arm D.



14. Remove cover (light). (Remove screw in arrow mark)



15. Remove the cover (right).





16. By above process, removal of [cover] has finished.

If you need to operate the machine with control box, please re-assemble the arm and the control box.

In a bid to prevent poor sewing finish or thread break, please keep places where thread contacts in the best condition.

- 1. Thread tension, detecting roller
  - a) Revolution must be smooth
  - b) No sticking of lint or dust






4. Needle

2. Ceramic and rim of take-up lever

a) No burr and crack



- 3. Thread path in lower side and needle holder.
  - a) No burr and crack



a) Needle tip shouldn't be warped or bent.


When you slide needle tip on surface of nail and if the nail gets scratched.

needle tip is warped. Please exchange it with new one.



Please place needle on flat surface and check clearance (A) from side. If clearance is not equal, needle is bent.


Please replace it with new one.




#### 5. Needle plate

a) No burr and crack in needle hole and around it.





- 6. Pressure foot
  - a) No burr and crack inside hole
  - b) Not bent



- 7. Rotary hook
  - a) No burr and crack.
  - b) Hook point not warped.
  - c) Backlash between bobbin case holder and outer hook should be less.



#### 8. Keeper

a) No burr and crack on tip.




# Fixing of needle

1. In order of (1)-(4), please remove and fix needle.

- (1) Loosen screw holding needle.
- (2) Remove needle.
- (3) Insert needle till it goes to the end.
- (4) Tighten screw holding needle.

Fix needle so that needle groove faces front.



#### 1. Selection of upper thread.

#### <Description>


Please select considering cloth, design of pattern and flavour etc.

<Thickness>

Please refer to [Relation between needle and upper thread 3-1-4].

- <Twist>
  - Z twisted thread is to be used.

(As rotary hook turns left- wise, Z twisted thread can prevent loosening of twist)



2. Selection of lower thread.

Basically please use cotton thread (#80-120), #120 is recommendable.

Pay attention to the following in selection.

- # Thickness should be equal.
- # When it is lightly stretched. it doesn't break easily.
- # In process of time, it doesn't get inferior.

Commercially available paper bobbin can be used, but please select thread with

thickness corresponding to cotton thread (#80-120).

When you prefer to use paper bobbin, please remove spring which is located inside the bobbin case.

\_\_\_\_\_

1. Description of needle

Basically please use [DB X K5] in standard accessory.

If description or thickness of cloth doesn't suit needle size, poor sewing finish / thread break / skipping will occur. Therefore careful attention is required in selecting needle.

2. Relation between needle and upper thread will be found below. (Representative example is shown.)

Needle - Size is [German 75] in standard accessory.

If necessary, please select in accordance with description of thread and cloth.

Thread - In case needle size is [German 75], if thread is rayon,[#120] is recommendable.

#### Relation between needle and upper thread


Need	Needle Size Description of upper thread and thickness					
Organ	German	Cotton	Silk	Polyster	Rayon	
8	60	100-130	140-160	150-200	50-70	
9	65	70.00	100-120	130-150	70-100	4
10	70	70-80	100-120	130-150	70-100	
11	75	50-60 36-40	80-100	100-130	100-130	Scope to be used for
12	80		00-100	100-130	100-130	general embroidery
13	85		60-70	80-100	130-150	
14	90		00-70	80-100	130-150	<b>v</b>
16	100	30-36	50-60	60-80	150-160	
18	110	24-30	40-50	50-60	180-230	

Denier(d)


If needle size and thickness of thread don't match, following problem will be likely to occur.

- Thread break
- Skipping
- Poor sewing finish

- 1. Referring to [2-1 Removal of outer covers], remove outer covers.
- 2. Remove the Rear cover.




3. Disconnect TC cable, Laser pointer cable and Front lighting cable.




4. Remove the thread tension bracket.

Thread tension bracket




5. Loosen screws located at right and left side, then take front cover off.


3-2-1




 Change needle bar to no.1 and no.7 with turning the gear by finger and remove all arrow marked screws, then remove the moving head.



7. Remove thread catcher ass'y



8. Remove face plate on the left.






- 9. Referring to [3-2-4 Exchange of needle bar driver],
  - remove needle bar driver ass'y.




10. Remove circuit board assembly for timing detecting



11. Remove Bobbin winder, power supply.

Screw 4 pcs


Bobbin winder




Power supply

12. Loosen screw on upper shaft collar, upper pulley,


#### drive pulley.



13. Loosen collar screw on take-up lever cam.




14. Loosen screw on crank.



15. Pull out upper shaft. (To the extent that crank comes out)




16. Remove Needle bar boss stopper.



17. Loosen fixing screws and pull down pressure foot guide bar and guide shaft.

Pressure foot guide bar


Guide shaft



18. Remove bearing retainer.




19. Remove crank ass'y.



 Put parts once removed back in reverse order
 For adjusting fixing of each unit, please refer to process to adjust fixing of each unit.


<Important> Pay attention to following (1) - (4).

- (1)Please fix upper shaft collar, upper pulley, drive pulley on flat surface of upper shaft with screw tightly.
- (2)Make sure that pulleys and collars are attached without space from machine body except upper pulley.



(3)Position of upper pulley is [2mm] from upper shaft collar.(3)Position of upper pulley is space from upper





Thickness gauge [11.5mm]

(4)Confirm that belt is not interfere the pulley flange and

not come out from pulley groove.

Adjustment will be done with following pulley.


Timing belt has to be adjusted with upper pulley position. Motor belt has to be adjusted with motor pulley position. 21. Please check and adjust timing mentioned below to finish.


(1)Upper shaft timing (L point, C point)


- (2)Take-up lever timing
- (3)Rotary hook timing
- (4)Jump device
- (5)Needle height

1. Referring to [3-2-1 Exchange of crank],

board ass'y, face plate (left) ass'y and moving head.








2. Referring to [3-2-4 Exchange of needle bar driver], remove needle bar driver ass'y.




3. Loosen screw on rod pin to remove rod.




4. Install good parts.

Please confirm that the number is printed on one side of the crank and this side should be located front. <Important> Leave space of [0.03mm] between crank and rod.



5. Put each unit back to where it was according to manual.


1. Loosen screw on detecting disk.



2. Turn upper shaft so that needle bar driver ass'y comes in the bottom.



3. When dial disc reads [0 degree], fix detecting disk.




- Work will finish by checking and adjusting timing mentioned below.
  - (1)upper shaft timing (L point, C point)
  - (2)Take-up lever timing
  - (3)Shuttle hook timing
  - (4)Jump device
  - (5)Needle height

Please use dial gauge for strict checking. Please see that timing on dial disc comes to [0 degree] when dial swings in highest value.




In case there is moving head, bring needle bar down.




Dial-gauge


1. Referring to [3-2-1 Exchange of crank],


Remove board ass'y, face plate (left) ass'y and moving head.












3. Pull out main shaft in head.



4. Loosen screw on lower part of needle bar driver ass'y.



5. Remove needle bar driver ass'y.



6. Install good parts.

#### <Important>


Make sure that Needle bar driver ass'y rotate smoothly and no clearance between rod and arm.



- 7. Put each unit back according to manual.
- After exchange, please be sure to adjust needle height.
   Please refer to [3-3-6 Adjustment of needle height].


#### <Attention>

Head shaft should be positioned slightly lower than ditch for oil.




## Adjustment of fixing of jump device

 Referring to [3-2-1 Exchange of crank], Remove moving head.




2. Move the rod of thre dcat cher nd Remove jump device.



3. Install good parts.


4. Install good parts.

Set upper shaft to [80 degrees] to adjust position of Jump shaft of jump device and Needle bar driver as illustrated below.



<Front view>


Viewing from front, Needle bar driver should come to center of Plunger.




Needle bar driver

<View from left>

This shows a state that plunger and Needle bar driver contacts.



5. Set upper shaft to [180 degrees] and confirm that the tip of the body is located at right side of the Head shaft center line.



 Please put parts back in reverse order to finish.
 For adjustment of fixing of each unit, please refer to process to adjust fixing of each unit.

## Exchange of take-up lever cam

- 1. Referring to [3-2-1 Exchange of crank], pull out upper shaft
- 2. Remove take up lever cam.



#### 3. Remove fasten collar.




 Put good parts back in reverse order.
 For adjustment of fixing of each unit, please refer to process to adjust fixing of each unit.

<Important> Pay attention to following (1) - (5)


(1)Please fix upper pulley, crank ass'y on flat surface of upper shaft with screw tightly. (2)Make sure that pulleys and collars are attached

without space from machine body except upper pulley.



(3)Position of upper pulley is space from upper

shaft collar.



Type of small collar


Thickness gauge [11.5mm]

(4)Confirm that belt is not interfere the pulley flange and not come out from pulley groove.Adjustment will be done with following pulley.Timing belt has to be adjusted with upper pulley position.Motor belt has to be adjusted with motor pulley position.

- (5) Please insert the Barrel cam into the Fasten collar first, then assemble it to the Upper shaft.
- 5. Please check and adjust the following timing to finish.
  - (1) lowest needle point
     (2) upper shaft timing (L point, C point)
     (3)Take-up lever timing
     (4)Shuttle hook timing
     (5)Jump device
     (6)Needle height (7) pressure foot

## Exchange of roller shaft ass'y

1. Remove take-up lever crank.



Push take-up lever shaft by slender shaft. (Hexagon wrench etc.)

Shaft Plain washer (M6) Take-up lever crank

20.6

#### <Attention>

Machine number ~1047001 is having a Plain washer

(M6) between Shaft and Take-up lever crank.

2. Exchange roller shaft ass'y.


#### <Spanner> 7mm, 8mm




 Insert bering positioning gauge [4.85mm] between bering and bering , and then tighten roller shaft ass'y.

Please adjust roller shaft for machine front side ways. This roller shaft ass'y is eccentricity. Turn lean screw and just touch roller to gauge.

Bering positioning gauge [4.85mm]




 Return take-up lever crank ass'y to previous place to finish.



Please push to arrow ways until stop.

#### <Attention>


Although the Take-up lever crank is assembled to the left side, but it is correct.



1. Loosen screw on fasten collar for take-up lever cam.




4. Turn take up lever cam slowly and insert positioning pin into pin groove.



pin groove

2. Set dial disc to [10 degrees].




3. Insert positioning pin from right side.



5. Loosen screw.

#### <Important>

Rotate the Take up lever cam clockwise until pin ditch touches to positioning pin then tighten the screw. (No gap between take-up lever cam and crank)




- 6. Pull out positioning pin.
- 7. Turn upper shaft and set dial disc to [C] to finish.

1. Remove screw on pressure foot cam.



2. Exchange pressure foot cam.




3. Put on grease to pressure foot cam.

<Grease>

Shell alvania EP Grease2


(Shell Gudas S2 V220 2)




4. Exchange has finished.

# Check of height of pressure foot

1. Bring pressure foot down. (Either way mentioned below)




(2)Turn gear with finger.




2. Bring needle bar down by finger.

Also you can move down the needle bar by maintenance mode through menu of control box.




3. Turn upper shaft and set dial disc to [0 degree].



4. Insert [Gauge I.2mm] between needle plate and pressure foot.

No gap between gauge and pressure foot or needle plate, will be OK.



In case the space is not 1.2mm, loosen the fixing screw and adjust height of pressure foot as following picture.



After adjustment, when pressing pressure foot to bottom with hand, confirm whether pressure foot turns back by spring.  Referring to [3-2-1 Exchange of crank], remove Front coverand Thread tension.



2. The needle which you insist to exchange pressure foot should be located at offset position from bed.




key on control box.




(2) Turn gear with finger.





3. Remove pressure foot.




4. Install good pressure foot.




5. Adjust height of pressure foot to finish.

Please refer to [3-2-10 Check of height of pressure foot].

1. Rotate the upper shaft to be lowest point [0 degrees].




2. Turn gear by finger, then bring pressure foot guide bar down.



3. Please confirm that the lenght of pressure foot gide bar should be 37 mm.

Also confirm that the pressure foot guide bar should not touch the LM guide, when the bar goes up to top



 In case the lenght of pressure foot gide bar is not 37 mm, loosen the screw which fixes guide bar block and adjust it as 37mm.




# Exchange of pressure foot link and block

 Referring to [3-2-4 Exchange of needle bar driver], remove the Head shaft and remove the Needle bar driver ass'y.




2. Loosen the screw which fixes guide shaft then move the guide shaft lower.



 If you exchange block ass'y, loosen the screw which fixes pressure foot link A then remove block ass'y.



- 4. If you remove the pressure foot link B ass'y, first remove
  - the pressure foot cam collar and pressure foot drive cam.



5. Remove pressure foot link B ass'y.




6. Assemble the parts by opposite procedure to terminate this exchange.


When assembling each unit, please refer to each procedure Instruction for assemble adjustment.

### <Attention>


Position of guide shaft is attached to lowest and the side of Head.




 Referring to [3-2-1 Exchange of crank], remove face plate.



2. Remove upper rail.



 Loosen fixing screw of guide bar boss and bring pressure foot guide bar down.



4. After remove pressure foot spring, remove pressure

foot guide bar to up side.




5. Remove pressure foot drive lever ass'y





6. Exchange pressure foot drive lever ass'y.




# Exchange of pressure foot drive lever

7. Put on grease to bady and oil bush of pressure foot lever ass'y.

<Grease>

Shell alvania EP Grease2

(Shell Gudas S2 V220 2)



10. Assemble pressure foot guide.



Oil insert bush

- 8. Put on grease to fulcrum shaft.
  - <Caution> Do not put on grease to a part of screw.



9. Assemble pressure foot drive lever ass'y.




3-2-14

11. Adjust position of pressure foot guide plate A ass'y.

#### <Caution>

Make sure that pressure foot guide plate A ass'y is mount perpendicular and parallel to the body.

<Spanner> 7mm




12. Adjust the height of pressure foot guide bar.

Please refer to [3-2-12 Adjustment of height of pressure foot guide bar].




13. Assemble the upper rail of moving head.

Please refer to [3-3-1 Assemble the upper rail of moving head].



14. Assemble the Needle bar boss stopper.



15. Assemble the face plate.




16. Install parts in reverse order to finish.For adjustment of fixing of each unit, please refer to process to adjust fixing of each unit.

3-2-15


 Referring to [3-2-1 Exchange of crank], Remove face plate (left) ass'y and moving head.

Loosen the screw and move the Guide bar boss B lower.




2. Remove pressure guide bar.

After remove pressure foot spring, remove pressure foot guide bar to up side.



3. Remove E-ring (E-4) which fixes guide bar boss.



4. Exchange guide.




5. Assemble the pressure foot gude bar and Pressure foot spring.



Adjust the height of pressure foot guide bar to finish.
 Please refer to [3-2-12 Adjustment of height of pressure foot guide bar.]




1. Change needle bar to no. 0 and disconnect cable from pulse motor.



2. Down the Pressure foot.




3. Disconnect cable from Sensor board ass'y and Remove bracket ass'y.




Cable from Sensor board ass'y

4. Remove drive gear A.




5. Exchange the pulse motor.

Fix it temporarily.



6. Assemble the drive gear A.

The position should come to the middle of the gear range.



7. Adjust position of pulse motor then fix it.

Keep slightly backlash between drive geer A and gear. (Every point.)


Remove clamp filter from original motor, then re-set to new motor.



 Continue to conduct [Adjust the pressure foot bracket ass'y].

Please refer to [3-2-17 Adjustment of pressure foot bracket ass'y].

1. Fix pressure foot bracket ass'y tentatively.




2. Lift up pressure foot.


4. Adjust position of pressure foot guide plate B ass'y.

### <Caution>


Make sure that pressure foot guide plate B ass'y is mount perpendicular and parallel to the body.



5. Procedure is done after confirming the pressure foot




on control box.







3. Pull pressure foot bracket ass'y downward, then fix it.




1. Tighten the screws securely while pushing thread catcher unit in the direction of the arrows of the following figure to fix the unit.



2. Loose screw of sensor for thread catcher unit a little bit.




- 3. Refer to "5-6-11 How to enter maintenance mode" and enter maintenance mode.
- 4. Press Machine Test



5. Press Catcher Adjust , take thread catcher unit in and out, and move and adjust the sensor shown in the direction of the arrow so that the dimension in the following figure meets the value in the following figure when hook goes back. Fix the sensor with setscrew after adjustment.





6. Continue to "Adjustment of thread holder".
When you adjust thread holder, you might need to adjust thread catcher unit again.
Follow the procedure in "3-3-13 Adjustment of thread holder."

- # Adjust if the thread is leans to one side.
- 1. Assemble the winder bracket ass'y tentatively.



2. Assemble the left cover with keeping the space between shaft and the cover hole.



3. Assemble thread tension ass'y.



4. Assemble guide as tentatively.




5. Confirm that the shaft does not touch the cover by turning motor.

(Set the empty bobbin and down the Guide.)




If the guide touches the bobbin adjust position of the winder bracket ass'y.



6. Adjust bobbin thread tension [30g] by tension gauge.



9.Adjust the height of Guide to adjust volume of thread to be winded.




7. Rewind the bobbin thread.


10. Reinstall the parts which has been removed.



8. Adjust the inclination of Winder bracket ass'y in accordance with thread winding condition.




Follow in picture, keep push to allow way each LM guide base.



### <Notice>


Should be front side which letter on side of LM guide base.



### Adjustment of backlash (back and forth) of moving head

 Adjust positioning roller shaft so as to put moving rail (lower) between bearings.

Move moving head back and forth so as not to cause backlash.




 After adjustment, check and adjust needle drop to finish Please refer to [3-3-4 Adjustment of needle position (back and forth)].

### Assemble the moving head

 Insert lower rail of moving head into 2 bearings of positioning plate ass'y.




2. Insert needle bar boss B into block ass'y, then insert forked part of take-up lever into take-up lever guide bar.




For above procedure, you need to turn link B by finger and move block ass'y till top position, then re-mount the moving head.

> Please note that Face plate (Left) is removed on the picture below just for taking photograph.




You also need to hold take-up lever by finger as a line.






3. Install moving head tentatively.




### <Caution>

Screw head not to come out from LM guide side.



4. Turn the Gear for manual operation,


and make it the 1st needles.



5. Tighten an inside screw (arrow portion in a figure).


#### <important>


Please perform a screw bundle in order of "inside to outside."




At this time, a moving head is pushed from the front and it is LM guide.

It is made for there to be no crevice.





6. An outside screw (arrow portion in a figure) is tightened.



7. Turn the Gear for manual operation,


and make it the 7th needles.



8. Tighten an inside screw (arrow portion in a figure).


### <important>


Please perform a screw bundle in order of "inside to




At this time, a moving head is pushed from the front and it is LM guide.

It is made for there to be no crevice.






9. Tighten an outside screw (arrow portion in a figure).



 Check center (right and left)(back and forth) of needle and needle hole of needle plate.(Needle No.1 ,4 and 7.)


#### <Caution>

Should be check needle No.1 ,4 and 7.



- 11. If not center (back and forth), please check the gap between LM guide and Moving head.If you find gap, please adjust again with procedure 4-10.If there is no gap, please refer to [3-3-4 Adjustment of needle position (back and forth)] and re-adjust the position.
- 12. If not center (right and left), please loosen fixing screws and adjust again with procedure 4-10.When all needles are displaced to same direction, please refer to [3-4-1 Fixing of needle bar change unit] and re-adjust the position.
- 13. If "OK". Please check [needle position].Refer to [3-3-5 Check of needle position].If "NG" this process, adjust again procedure 11-12.


1. Bring pressure foot down. (Either way mentioned below)



 Turn upper shaft and set needle near to the lowest needle position [L] to adjust positioning plate ass'y.




- \* Insert Lower rail to between the two bearing deeply.
  - (This is for setting of Moving head completely.)



2. Bring needle bar down by finger.

Also you can move down the needle bar by maintenance mode through menu of control box.





positioning plate ass'y

Viewing from side, set to center of needle hole. #Check and adjust with 1st, 4th and 7th needle.



 After adjustment, please be sure to check and adjust clearance between needle and shuttle hook.
 Please refer to [3-5-1 Adjustment of rotary hook timing].

### Check of needle position


 $1. \mbox{ A main switch is turned on.}$ 

The **Next** is pressed and it changes into an operation state.




and make it the 4th needles.


3. Stick a seal on needle hole of a needle plate.



4. Bring pressure foot down. (Either way mentioned below)



(2)Turn gear with finger.



5. Bring needle bar down by finger.


Also you can move down the needle bar by maintenance mode through menu of control box.



 Turn an upper axis up to [302 degrees - 303 "], and it is the needle mark to a seal. A hole is made.

<Note> Needle point will become large if the angle of a dial disc is made into 304 degrees or more.

An exact needle position check becomes impossible.



 Reverse-rotate an upper axis, raise a needle bar, and unite with C [275 degrees].

(It returns to 303 degrees-> 220", and unites with 275 degrees after that.)

<Note> If a top axis is right-rotated, a needle will enter deeply, and needle hole is greatly.

It becomes. Therefore, an exact needle position check becomes impossible.

 1st needle and the 7th needles are to 302 degrees - 303 degrees about an upper axis by the above-mentioned procedure. It turns, a needle is lowered and a needle position is checked.

It will be O.K. if the needle point goes into the seal hole made by the 4th needles at this time.

- \* If "NG". Please adjust again, follow to [3-3-3 Asemble the moving head] of procedure 6-10.
- \*  $303^{\circ} \rightarrow$  Diameter of  $\varphi 0.2$ mm,  $310^{\circ} \rightarrow$  Diameter of  $\varphi 0.5$ mm The order which the screw which is fixing the move head fastens -- from an inner side. If it does not carry out correctly outside, a needle position will shift -- it is -
- 9. Un-stick a seal on needle plate to finish.


3-3-5

# Adjustment of needle height


 Referring to [3-2-1 Exchange of crank], remove lower front panel.




2. Remove bobbin case.




3. Bring pressure foot down. (Either way mentioned below)




(2)Turn gear with finger.



4. Bring needle down.




5. Turn upper shaft to set dial disc to [5 degrees].



6. Loosen needle bar boss and needle bar boss B.

Needle bar boss B



Needle bar boss

7. Put needle height gauge in rotary hook.




 Adjust the needle bar height up and down till the needle tip touches to the gauge slightly.



9. Set direction of needle stop as illustrated below.






10. Tighten the screw of needle bar boss.



- 11. Bring pressure foot down and Turn upper shaft to set dial disc to [270 degrees]..
- 12. Tighten the screw of needle bar boss B.When tightening needle bar boss B, please insert <u>Calliper (pre-set as 25.3mm)</u> in-between.
  - \* Check the movement of needle bar goes smoothly.





13. Put things back in reverse order of 1-2 to finish.

1. Referring to [3-2-1 Exchange of crank], remove lower front panel.




The needle which you insist to exchange needle bar should be located at offset position from bed.






3. Remove needle, needle holder and pressure foot.




4. Loosen needle bar boss and needle bar boss B.



Needle bar boss

(2) Turn gear with finger.



5. Pull out needle bar.


At this moment, remove needle bar boss, needle bar bossB, Needle bar spring H, Pressure foot block B, Pressure foot spring, Cushion and Plain washer (M6).



 While pressing needle bar spring, insert good needle bar with needle bar boss, needle bar boss B, Pressure foot block B, Cushion, Plain washer (M6), Needle bar spring H and Pressure foot spring.



7. Fix needle , needle holder and pressure foot.




8. Adjust needle height.

Please refer to [3-3-6 Adjustment of needle height].


3-3-7

9. Put removed parts back to finish.


 Referring to [3-2-1 Exchange of crank], remove moving head.



2. Remove Clamp of laser pointer cable.





3. Remove Block plate.




4. Remove boss screw.

Please note that you need hexagonal driver for front screw and spanner (4mm for rear nut as photo below.







5. Exchange of needle bar boss guide plate and fix it. Push needle bar boss check plate to arrow marked direction and keep the length of both sides equally as photo below, then fix screws.




- 6. Fix boss screw again.
- 7. Fix block plate temporary.



8. Fix Clamp of laser pointer cable temporary.




- Referring to [3-3-3 Assemble the moving head],
   Put moving head and other removed parts
- Adjust height of block plate and confirm that pressure foot block B should goes into groove of guide bar boss B as photo below, then fix screws.




11. Put moving head and other removed parts back to finish.


 Referring to [3-2-1 Exchange of crank], remove moving head.




2. Loosen screw on take-up shaft.



3. Remove the E-ring.



4. Remove the take up lever shaft first then remove the takeup lever.



5. Install take-up lever assembly.



 Leave space of [0.03mm] between take-up lever and moving head, then set the E-ring.




7. Put moving head in previous position to finish.


1. Referring to [3-2-1 Exchange of crank], remove Front cover.




2. Remove Thread guide ass'y.



 Insert (-) screw driver as picture below and slide the thread guide to arrow marked direction, then you can remove the thread guide.




4. Remove Thread adjusting plate and Thread adjusting spring.





5. Exchange thread adjusting spring.

Set the thread adjusting plate and thread adjusting spring to same position as picture below.



6. Put removed parts back in reverse order.


1. Referring to [3-3-10 Exchange of thread adjusting spring], remove Thread guide.



2. The Thread adjusting plate has a latch to be able to adjust tension in three steps.

Loosen screw of the thread adjusting plate, then you can adjust the latch to desired position.

Also the thread adjusting plate have five spring grooves for fine adjustment.



Spring groove (Fine adjustment)


3. Put removed parts back in reverse order.

# Adjustment of laser pointer


1. Referring to [3-2-1 Exchange of crank], remove Font cover.



 Set paper on needle plate and make first hole on the paper.
 Moreover, please make each 1 hole in the left, right, up or down which separated about 20 mm from the first hole.




Holde the laser pointer unit by 10mm wrench,
 Loosen nut to the extent that laser pointer unit moves.



Laser pointer unit

<Spanner> 10mm

- 4. Press key on display of control box.
- Adjust position and angle of laser pointer that the ray of laser should goes into theneedle hole.
   Fix the nut.



6. Put moving head and other removed parts back to finish.


1. Referring to [3-2-1 Exchange of crank], remove Font cover.




2. Loosen screw to the extent that thread holder moves.




3. Bring pressure foot down. (Either way mentioned below)



(2)Turn gear with finger.




 Take the hook in and out by finger to check movement of hook goes smoothly. Check this at 1th , 4<sup>th</sup> , 7<sup>th</sup> needle.



<Positional relationship between hook and holder (lower)>




 If you can not set the correct position with procedure no.4, then Thread catcher device should be adjusted.



- 6. Check up with thread trimmer function.
- 7. Assemble lower front cover to terminate this procedure.


1. Referring to [3-2-1 Exchange of crank], remove Font cover



2. Remove thread holder ass'y.



3. Remove holder (lower).




4. Exchange the majic-tape.




<View from bottom>

Stick position for velcro strap



5. Assemble holder (lower).



 Install holder ass'y to moving head in reverse order to finish.


Please refer to [3-3-13 Adjustment of thread holder].

1. Place needle bar change unit assembly.


please set positioning hole on unit assembly to

positioning pin.


Insert arrow marked screws temporary. Connect cable.




 Turn slit collar and adjust angle that groove of slit collar should be located same position of sensor. Refering to 4-2-3 [Adjustment of stop position of needle bar change unit]




Confirm that the slit does not tough the sensor.




3. Turn drive gear B by finger and set needle bar to no.4.



4. Bring pressure foot down. (Either way mentioned below)




(2) Turn gear with finger.



5. Bring needle down, turn upper shaft to set near to [L point].




 Adjust position of unit assembly so that needle comes to center against needle hole on needle plate.




 Return other parts to previous.
 For adjustment of fixing of each unit, please refer to process to adjust fixing of each unit.

- 8. Please check and adjust the following timing to finish.
  - (1)Shuttle hook timing(2))Needle height
  - (3) pressure foot

## Adjustment of rotary hook timing







3. Tighten screw on rotary hook. (3 places)



2. Bring pressure foot down. (Either way mentioned below)



(2)Turn gear with finger.



4. Bring needle bar down by finger.

Also you can move down the needle bar by maintenance mode through menu of control box.




5. Turn upper shaft and set dial disc to [25 degrees].

### Adjustment of rotary hook timing

6. Adjust rotary hook timing.


This procedure is preconditioned to use needle type

[DB-K5] in which contains with our standard accessory.



At this moment, clearance between needle and rotary hook should be [0.1-0.2mm]. Check and adjust with 1st, 6th and 12th needle and


tighten screws.







7. For making sure, check position of retainer on bobbin case holder.

Please refer to [3-5-2 Adjustment of retainer on rotary hook] for adjusting value and follow it.




8. Adjustment has finished.






1. Loosen screw to the extent that retainer on bobbin case holder moves.




- 2. Install screw for Needle plate. (only front side)
  - (This avoid interfere of screw and Rotary hook retainer during installing Needle plate)



3. Adjust position back and forth, left and right.

Tighten screws.

Space has to be [0.8mm] and the position right and left is center of the needle.



4. Adjustment has finished.


1. Assemble the arm ass'y tentatively.



2. Hold arm to backward and tighten only hithermost screw.

#### <Caution>


Make sure that there is clearance between arm and body.



3. Hold the left side of arm to body and tighten screw.




 Hold the right side of arm to arrow pointed direction at below picture and tighten screw.



5. Assemble detecting plate.


Make sure that detecting plate is mount perpendicular and parallel to the arm.



6. Check of interference between detecting plate and two sensors or connector of sensor board.


#### A part of sensor

Detecting plate




Sensor

Conector Sensor



A part or conector




 Adjust by bending detecting plate by hand if you find any interference with sensor or connector.



8. Finish this process.

- 1. Referring to [3-2-1 Exchange of crank], Remove Thread stand and outer covers.
- 2. Referring to [3-7-4 Exchange of Y carriage belt], Remove arm.


5. Loosen the screw for coupling of the Y carriage.



11. Remove Bobbin winder, power supply.


#### Screw 4 pcs

Bobbin winder




Power supply


4. Disconnect cable from sensor board.



6. Remove the screw of Y carriage bracket (left).




7. Remove the Y carriage.




3-6-2


8. Remove thread cutting driver.




9. Disconnect cable.




10. Remove Pulse motor.



12. Remove Drive gear.



Install Drive gear on good Pulse motor
 Position of Drive gear is space from Pulse motor.




- 13. Place parts back in accordance with manual.
- 14. Check and adjust position of moving knife to finish.

Please refer to respective adjustment.

## Exchange of moving knife

1. Remove needle plate.



 Remove knife drive shaft retainer. (Screw : 2 pcs)
 Open moving knife when you cannot access hidden screw.




3. Pull out knife drive shaft ass'y.



4. Exchange moving knife.



 Setting drive link hole to moving knife, insert knife drive shaft assembly.



6. Pushing down moving knife and knife drive shaft retainer like putting them together, fix knife drive shaft retainer.
# Fix so that there is no backlash in upward and downward direction.


Close moving knife




 Referring to [3-6-8 Adjustment of moving knife and fixed knife],check how well thread is cut and adjust, then finish this process.

## Exchange of fixed knife

1. Remove needle plate.



2. Open moving knife first, then remove fixed knife.



4. Tighten fixed knife pushing to forward as full as possible and close moving knife



#### <Notice>

In case moving knife and the left side of fixed knife overlaps excessively when closing, adjust the position of fixed knife slightly to the right direction.

 Referring to [3-6-8 Adjustment of moving knife and fixed knife],check how well thread is cut and adjust, then finish this process.

3. Exchange fixed knife.



### Adjustment of moving knife and fixed knife

1. Remove needle plate.




2. Open moving knife, check if knife drive shaft has no backlash in up and down direction.

If backlash is found, adjust it referring to [3-6-6 Exchange of moving knife].


Close moving knife



3. Adjust slant of fixed knife with [upper adjustment screw] and [lower adjustment screw] that fix fixed knife.
<Note> Rub these screws together to the extent that you don't feel resistance.



<Spanner> 5.5mm




4. Cut thread and check how well it is cut. Use two polyester threads for checking.



5. Check several times and if no mistakes are found, finish this process.

1.Remove Needle plate and Cover (front).




- 2. Enter maintenance mode in reference to [9-1 How to enter maintenance mode]
- 3. Press Machine Test .

[ MAINTENANCE ] / (	[ Machine Test ]
# 1 Needle Adjust	# 6 Catcher Test
# 2 Cutter Adjust	# 7 Cutter test
# 3 Catcher Adjust	# 8 Clip Solenoid test
# 4 Keeper Test	# 9 Pointer test
# 5 Jump Solenoid Test	#10 Fan Drive test ESC

4. Press #2 Cutter Adjust,


# 2 Cutter Adjust			
Step close	Separate	Adjust Mode	

 Press Separate, then the Moving knife will be opened.
 Please confirm that the tip of Moving knife is located at center of Rotary hook retainer.





Tip of moving knife

 In case the tip of moving knife is not in the right position, loosen screw on Thread cutting rod, then adjust position of the Moving knife with turnning Eccentric pin. Tighten screws.



 Press Origin, then the Moving knife will be closed.
 Please confirm that the Moving knife is located as drawing below.






Adjustment of clearance between moving knife and fixed knife is where both tip of then are attached.

- 8. Press Separate and Origin by turns to confirm that t he Moving knife is closed in the right position.
  Press ESC to finish 「Maintenace mode」.
- If necessary, please refer to [3-6-8 Adjustment of moving knife and fixed knife] and check how well thread is cut, then finish.

# Adjustment of bobbin thread holder

1. Remove needle plate.




2. Close moving knife like putting bobbin thread between moving knife and bobbin thread holder.



 Through height of bobbin thread holder, you can adjust holding power for bobbin thread.

Pull bobbin thread toward arrow mark and adjust the height by screw thatbobbin thread comes off with tensile gauge [20-25g].






4. Tighten lock nut. (Don't move adjusting screw.)



5. Check several times and if OK, finish this process.


### Exchange of keeper solenoid

1. Remove Bed cover (lower) and take connector of Keeper solenoid out.



Connector


2. Remove E-ring on fulcrum pin.



3. Remove keeper solenoid ass'y.




4. Exchange keeper solenoid.




#### <Attention>

Pushing keeper solenoid to solenoid base. Insert <u>2.0mm thickness gauge</u> between solenoid base to polyslider.



2.0mm thickness gauge

<Front view>




Clearance between keeper plunger and solenoid base should be kept as much as equally.

 Put keeper solenoid ass'y in previous position then adjustment of position of keeper to finished.
 Refering to [3-6-12 Adjustment of position of keeper].

## Adjustment of position of keeper


 Remove bed cover (lower), then loosen screws on solenoid base and stopperbracket.



2. Insert keeper positioning gauge (Bobbin) into rotary hook.



2. Insert [2.0mm] clearance gauge between solenoid base and slider then pull in keeper solenoid and keeper rod.




 Confirm that tip of keeper does not touch thread guide of bobbin case.

When tip of keeper touches thread guide, adjust it by bending keeper.

5. Adjust solenoid base where tip of keeper contacts slightly to the gauge then tighten bracket screw.

Clearance between bobbin and keepr is [about 1.0mm].




<View from right>

Keeper positioning gauge About 1.0mm (Bobbin) Keeper

6. Adjust position of stopper.

This is the position where tip of keeper contacts to gauge




6. Adjustment has finished.

## Adjustment of X carriage belt tension

1. Remove frame base.



4. Remove X carriage cover. (Screw : 2 pcs)




2. Disconnect X carriage cable.



5. Remove sensor bracket.



3. Remove X carriage. (Screw : 2 pcs)



 Loosen fixing screw for tension pulley bracket slightly. (front side)



### Adjustment of X carriage belt tension

7. Loosen fixing screw for tension pulley bracket slightly.


#### (rear side)




8. Adjust belt tension.

Use push and pull gauge.


- <Adjustment value>
  - [200g] at the status of which both belt is touch.






<Note> Slide connecting plate to right as full as possible.

Gauge in the middle of idler pulley and tension pulley.



Adjustment, tighten fixing screw for tension pulley bracket.



9. Tighten fixing screw for tension pulley bracket. (front side)




10. Tighten fixing screw for tension pulley bracket. (rear side)



11. Return things back to previous places in reverse order.

# Exchange of X carriage belt

1. Remove frame base.



4. Remove X carriage cover.




2. Disconnect X carriage cable.



5. Remove sensor bracket.



3.Remove X carriage.



6. Loosen screw for tension.



# Exchange of X carriage belt

7. Remove the screw which fixes tension bracket.

Remove the plate nut located other side.




8. Loosen screw (rear) slightly to the extent that tensionbracket moves.




9. Remove belt from motor pulley.



10. Remove connecting plate.





11. Exchange belt to good one.


#### <Important>

Exchange it so as not to break groove and convex on belt of connecting plate.



12. Adjust the position of belt.

Space between edge of X base and belt is [10mm].



- Referring to [3-7-1 Adjustment of X carriage belt tension], adjust tension of belt.
- 14. Put removed screw and nut plate.
- 15. Return X carriage assembly and frame base to previous places to finish.

## Adjustment of Y carriage belt tension

- 1. Referring to [2-1 Removal of outer covers], remove outer covers.
- 2. Remove cover (front), referring to [3-6-1 Assemble the arm ass'y], remove arm.
- 3. Loosen lock nut for tension adjustment screw.






5. Adjust belt tension, to use belt tension gauge.

Use push and pull gauge.


<Adjustment value>

Adjusted to be [200g] at state that Belt attaches to Rail.



Push belt holding plate backward as full as possible.


Gauge in the middle of idler pulley.




Adjust with screw.



4. Loosen tension screw so as to move tension.



6. Tighten screw on tension.



7. Tighten lock nut for tension adjustment screw.




8. Put other removed parts back to finish.

## Exchange of Y carriage belt

- 1. Referring to [2-1 Removal of outer covers], remove outer covers.
- 2. Remove cover (front), referring to [3-6-1 Assemble the arm ass'y], remove arm.
- 3. Loosen lock nut for tension adjustment screw.
  - <Spanner> 7mm



4. Loosen tension screw so as to move tension.



5. Loosen screw for tension.



6. Remove belt holding plate.




7. Exchange belt.



8. Set belt to belt groove of guide frame base.
<Important>Exchange it so as not to break belt tooth and convex on belt.



Do not put belt tooth on the innermost groove of the connecting plate.



9. Fix belt holding plate.



- 10. Referring to [3-7-3 Adjustment of Y carriage belt tension], adjust tension of Y belt.
- 11. Put other removed parts back to finish.

## Adjustment of timing belt tension

- 1. Remove bobbin winder.
- 2. Remove Bobbin winder, power supply.

Screw 4 pcs

Power supply

Bobbin winder


- 3. Adjust tension of timing belt.
  - <Important>

Tension shaft ass'y to be set at the center against screw hole of the body.

No need to adjust tension.




Please move tension shaft ass'y upward and downward to adjust.



- 4. Please return power supply to previous places.
- 5. Please return bobbin winder to previous places then adjustment to finished.

## Exchange of timing belt


- Referring to [3-2-1 Exchange of crank], Remove thread stand, outer covers, thread tension, front panel, moving head and face plate.
- 2. Remove timing detecting board ass'y.
  - Cable 1 pcs, Screw 2 pcs



2. Remove winder and power supply.

Screw 4 pcs

Winder



Power supply


Remove support roller ass'y.




- 3. Loosen screws on upper shaft collar,
  - upper pulley and drive pulley.



4. Loosen screw on fasten collar for take-up lever cam.



5. Loosen screw on crank.




### Exchange of timing belt


6. Pull out upper shaft.



7. Remove upper pulley and timing belt.

Install good timing belt.






 8. Install parts in reverse order.
 For installation and adjustment of each unit, please refer to respective manuals.

Referring to [3-8-1 Adjustment of timing belt tension], adjust tensile strength of timing belt.


- <Important> Pay attention to following (1) (4).
- (1)When you install upper shaft collar, upper pulley, drive pulley and crank, please fix them on flat surface of upper shaft with screw.
  - (2)Make sure that pulleys and collars are attached

without space from machine body except upper pulley.



(3)Position of upper pulley is space from upper

shaft collar.



Type of small collar

Thickness gauge [11.5mm]

(4)Confirm that belt is not interfere the pulley flange and not come out from pulley groove.Adjustment will be done with following pulley.

Timing belt has to be adjusted with [upper pulley position]. Motor belt has to be adjusted with [motor pulley position].


- 9. Check and adjust following timing to finish.
  - (1)Lowest needle point
  - (2)Upper shaft timing(L point, C point)
  - (3)Take-up lever timing
  - (4)Rotary hook timing
  - (5) Needle height
  - (6) Height of pressure foot

# Adjustment of motor belt tension

- 1. Referring to [3-2-1 Exchange of crank], Remove thread stand and outer covers.
- 2. Remove winder and power supply.


Screw 4 pcs


Winder



Power supply

3. Remove two screws shown in the following figure and inverter.






4. Loosen screw on motor bracket.








### Adjustment of motor belt tension

5. Adjust motor belt tension.


Use push and pull gauge.

<Adjustment value> 320 - 330 g / 3mm




Gauge in the near center between drive pulley and


motor pulley.



Adjust of tension should be 320 – 330g at belt is pressed 3mm.




Move main motor upward and downward to adjust.



6. Tighten screw on motor bracket.





7. Return power supply bracket, power supply, bobbin winder and inverter to previous places to finish.

## Exchange of motor and motor belt


- 1. Referring to [3-2-1 Exchange of crank], Remove thread stand and outer covers.
- 4. Loosen screws on upper shaft collar, upper pulley and drive pulley.



5. Loosen screw on fasten collar for take-up lever cam.




6. Loosen screw on crank.



2. Remove timing detecting board ass'y.






3. Remove winder and power supply.

#### Screw 4 pcs

Winder




Power supply

3-8-4


### Exchange of motor and motor belt

7. Pull out upper shaft.



8. Remove drive pulley and motor belt.

Install good motor belt.






 Install each parts in reverse order.
 For installation and adjustment of each part, please refer to respective manuals.


Referring to [3-8-3 Adjustment of motor belt tension], adjust tensile strength of motor belt.

- <Important> Pay attention to following (1) (4).
- (1)When you install upper shaft collar, upper pulley, drive pulley and crank, please fix them on flat surface of upper shaft with screw.
  - (2)Make sure that pulleys and collars are attached
    - without space from machine body except upper pulley.



(3)Position of upper pulley is space from upper

shaft collar.



Type of small collar

Thickness gauge [11.5mm]

(4)Confirm that belt is not interfere the pulley flange and not come out from pulley groove.

Adjustment will be done with following pulley.


Timing belt has to be adjusted with [upper pulley position]. Motor belt has to be adjusted with [motor pulley position].

- 10. Check and adjust following timing to finish.
  - (1)Upper shaft timing (L point, C point)
  - (2)Take-up lever timing
  - (3)Rotary hook timing
  - (4)Jump device


#### Remove LCD-CE board

1. Remove four setscrews as shown in the figure below

#### and remove rear cover.




- 2. Remove connectors for SW cable, Box cable, cable for
- LCD inverter (red/white).



Cable for LCD inverter (red/white)


3. Remove set screw and sealed case A.




4. Remove core module.




5. Remove narrow flat cable for LCD unit.



When you pull the latch to cord side, the cord release. When you push the latch to connector side, the cord fixed.




6. Remove two sets screws and two studs.



7. Lift LCD-CE board as shown in the figure below.


Remove wide flat cable for LCD unit.

(When the tape for fixing is stuck on connector, please peel off.)




Wide flat cable


When you pull the latch to cord side, the cord release. When you push the latch to connector side, the cord fixed



8. Remove four setscrews and LCD unit.



9. Remove touch panel.



Please reverse procedure when installing LCD-CE board.

### Setting for LCD-CE board


#### Memory card

Insert our official memory card (EPZ01220). Refer to the latest parts list for the parts number.

This memory card contains programs and data for an embroidery machine.

<Notice> Please contact us if you need to use third party's memory card from local market.

The necessary information will be provided.



#### Coin battery (Ser.No. ~1002003)

Insert our official coin battery (EPZ01190).

Refer to the latest parts list for the parts number.

The battery is used for back-up power source of real-time clock on an embroidery machine.

Replace new battery if clock dose not indicate the correct time after setting a clock and turning power switch OFF.



#### Disposal of coin battery of LCD-CE board




Dispose of a coin battery by following the method specified by each country or each region.

# Power supply settings

(Disconnect power plug from electrical outlet before work.) (Please use digital output tester)

 Turn the machine on and put tester against terminal plate or connector, then turn V-ADJ to adjust to [24.6V±0.1V].

for 100V For 200V



VR

4-2-1


1. Remove bobbin thread winding motor ass'y.




2. Fix 2 screws tentatively timing detecting board.




3. Set upper shaft to [0 degree].



 Move circuit board up and down and set to position where LED 2 disappears at [0 degree], then fix with screw.





5. With this state, turn to C point and check if LED1 lights between [265 and 282 degrees].



- \* Check dose not scratch plastic slit to Timing sensor.
- 6. Put bobbin thread winding motor ass'y back to where it was.


Viewing from side of circuit board, set slit so that it comes to center of sensor has to be same as the picture below.






# Adjustment of stop position of needle bar change unit 4-2-3


Sensor board







Imagine figure of position sensor and cam

Set position where sensor on sensor board and slit don't cross to area where moving head doesn't move when turning groove cam.







# Remove of Inverter


#### <Notice>

Please disconnect machine inlet from the wall. <Check>

Before you start to work, make sure the display of inverter is off.

- 1. Remove outer cover. Refer to [2-2 How to remove outer cover].
- 2. Remove control terminal cover.


Insert fingers in a gap (under the "PULL" indication) on the underside of control terminal cover, and pull the cover toward yourself and remove it.




If screw is provided on the cover, remove it.

3. Remove main terminal cover


Hold both left and right ends of main terminal cover with fingers and slide the cover toward yourself and remove it.




 Loosen screw with Phillips screwdriver for precision instrument and remove 9 cables. (Cable color: ORANGE, BROWN, PURPLE, WHITE, GREEN, BLUE, YELLOW, BLACK, and GLAY)




 Remove screws with Phillips screwdriver and remove power cable and motor cable. (Cable color: GLAY, WHITE BLACK, BLUE, and BROWN)




6. Remove cable from clamp.




7. Remove two screws shown in the following figure and inverter.







End of process.



Inverter for 110 - 120V



Inverter for 200 - 230V



# **Inverter Installation**

#### <Note>

Please check your replacement inverter type and machine Voltage specification before replace inverter.

Sticker on inverter

For 110 - 120V

HCS 110V TYPE E S H C B 7 9 5 7\*


For 200 - 230V

HCS 230V TYPE
$\mathbf{E}~\mathbf{S}~\mathbf{H}~\mathbf{C}~\mathbf{B}~7~9~5~\mathbf{6^{*}}$

Refer to specification sticker for voltage specifications of the machine.

1. Remove control terminal cover.


Insert a finger in a gap (under the "PULL" indication) on the underside of control terminal cover, and pull the cover toward yourself and remove it.



2. Remove main terminal cover


Hold both left and right ends of main terminal cover with fingers and slide the cover toward yourself and remove it.

Main terminal cover





3. Install inverter in the machine with two screws tightened.







4. Tighten screws with screwdriver to install power cable and motor cable per the following connection diagram.(Cable color: GLAY, WHITE, BLACK, BLUE, BROWN)






 Tighten screw and connect 9 cables the following connection diagram. (Cable color: ORANGE, BROWN, PURPLE, WHITE, GREEN, BLUE, YELLOW, BLACK, and GLAY)





6. Fix cable to the clamp.





7. Set main terminal cover

Install main terminal cover

Hold both left and right ends of main terminal cover with fingers and install the cover in the inverter <Note>

Install main terminal cover not to apply stress to the cable. If stress is applied to the cable, load is applied to the screws for the main terminal and the screws might be loosened.






8. Install control terminal cover

Install the cover by inserting the nail on top of the cover to the ditch of the inverter.

Do not pinch any cables with the cover.



9. Referring to [4-4-4 Setting of revolution], Perform [Initializing of machine speed].

Inverter Installation is done.

#### <Note>

Check if voltage specifications of the machine and inverter

are matched before installation.


In case of spare parts supply, parameter is preset. Please contact HAPPY, when you need to change it. Parameter cannot be set while machine is running .

Pay attention to electric wires as setting is done with power is on.

How to release the setting change prohibition

Release the prohibition by following the procedures below

since parameter is set as setting change prohibition.



### 1. Press PRG/RESET.

[ I.F \_ \_ ] is displayed.

### 2. Press FUNC/DATA

[F 00] is displayed.

### 3. Press FUNC/DATA again.

[ 1] is blinking.

(This means setting change is prohibited.)

### 4. Press Up key or Down key while pressing STOP

[ 0] is blinking.

(This means you can change settings.)

### 5. Press FUNC/DATA.

After [SAVE] is indicated,

[F 01] is displayed.

By above process, you will be able to set parameters.

Next, change each setting.

6. Press Up key and function code is displayed. Select the function code whose parameter you would like to change. (Press Up key and the function code returns to the previous code.)

The following table shows function codes, setting details, and factory default setting. Functions other than described below are initial setting of inverter.

Refer to the next clause for the method of initial setting.

Code F	unction	→	Setting	
F00	Prohibition of change	→	1	( Protect )
F01	Frequency set mode	→	1	
F02	Drive / Operation	→	1	
F03	Maxmum frequency	→	85.0	
F05	Base frequency volteage	· →	200	
F07	Acceleration time 1	→	2.0	
F08	Deceleration time1	→	0.5	
F11	Motor thermal protection	→	0.63	
F15	Upper limit freq. limter	→	85.0	
F20	DC brake. starting freq.	→	1.0	
F21	DC braking current	→	30	
F22	DC braking time	→	0.5	
F23	Start frequency	→	0.5	
F26	Carrier frequency	→	6	
F27	Tone	→	2	
F37	Load selection	→	2	
C05	Multi stage frequency 1	→	2.3	
C33	Analog input filter	→	0.05	
C34	Analog input adjustment	→	50.0	
C50	Bias frequency	→	0.0	
P02	Motor capacity	→	0.09	
P03	Motor rated current	→	0,63	

7. Select the code you would like to change and press

### FUNK/DATA

Parameter of the function is displayed.

8. Change parameter by pressing Up or Down key.

### 9. Press FUNK/DATA.

After [SAVE] is displayed, the next function code is displayed. This means change of the function code is made.

### How to set the prohibition setting

10. After each setting is done, select [ F 0 0 ] by pressing Up or Down key to return to setting change prohibition.

### 11. Press FUNC/DATA.

- [ 0] is blinking.
- 12. Press Up key while pressing STOP.
  - [ 1] is blinking.

### 13. Press FUNC/DATA.

After [ S A V E ] is displayed,

[F 01] is displayed.

### 14. Press PRG/RESET.

[I.F\_\_] is displayed.

### 15. PRG/RESET again.

Return to normal mode.

Please note that you are unable to make this setting while the machine is running.

When setting is mistakenly made in mid way, the setting will return to parameter in normal standard in one action.

Thereafter please change to parameter you want to set.

 Enable parameter to be changed by referring 1. to 5. in [How to set inverter].

### 2. Press PRG/RESET.

 $[ \mbox{ I.F } \_ \_ ] \mbox{ is displayed.}$ 

3. Select [ I.H \_ \_ ] by pressing Down key 3 times.

### 4. Press FUNC/DATA.

[H 03] is displayed.

### 5. Press FUNC/DATA again.

- [ 0] is displayed.
- 6 Press Up key while pressing STOP.
  - [ 1] is displayed.

### 7. Press FUNC/DATA.

After [ S A V E ] is displayed,

[ 0.06] - [ 0.07] is displayed.

### 8. Press FUNC/DATA.

[I.F\_\_] is displayed.

The settings of inverter become initial settings.

Then, change parameter and return to prohibition setting by referring to the previous clause.

\* The sequence of procedures of program update is described below.. If you need more details, please refer to each manual.

1.	Insert the updated program downloaded USB memory to the USB port of the machine	>
	with its power turned "OFF".	Maintenance Manual
	Press NEXT while pressing START/STOP button of the control box at the screen after	4-4-3 Machine program and Main program update
	the machine is booted.	
2	. Enter maintenance mode and update program from the menu.	
3.	. Press [MENU] button and select [System] in menu of [OTHER] for initialization of system.	Instruction book 25-1.2 Initialize machine
4	. Press [MENU] button and select [Speed] in menu of [OTHER] for automatic speed setting.	
5.	. [Replacement of LCD-CE board]	Instruction book
	Calender setting	Solution > 3-7 Calendar setting
_		-

6. end of process

\* Download updated program file and decompress the file.

#### Program

for HCD2, HCS2, HCH, HCH Plus " "MainProgramA\*\*\*\* "

\*Copy the decompressed file(s) or the folder that contains decompressed file to USB memory. File names on your PC are shown below:

Program for HCD2, HCS2, HCH, HCH Plus "UpDateFile"

### <NOTE 1>

Copy the program to the root folder of USB memory.

### Machine program and Main program update

1.Insert USB memory that contains data for version up into insertion slot on the control box.


2. Press

(MENU) and press

(OTHER).




3. Press Version .



### 4. Press UPDATE

### Installation of program begins.



### <NOTE>

- \* Please do not take out USB memory during installation.
- \* Please do not turn off the power during installation (it will
  - take for a while for completion of installation).

Retry updating when the screen shows "Error" due to writing error.

Once update id complete, the machine will be rebooted automatically.



### 5. Press NEXT button.

- Referring to [4-3-5 Setting of revolution],
   Perform [Re-Initialization of machine system]
   And [Initializing of machine speed].
- \* End of process.

## Setting of revolution

### **Re-Initialization of machine system**

Perform this function only to fix problems with the machine.


When performed, all settings in the "OPTION" menu are lost.

Be sure to reset the "OPTION" menu after performing this function.

1. Turn on the power. After the program start up, press



2. Press System .



3. Press OK .

Formatting of the machines systems are carried out.

Indicate HAPPY logo in screen.


End of process.

### Initializing of machine speed

Setting of revolution of main shaft, which is suitable to the machine is required.

If setting is not done, the revolution may not speed up.


1. Turn on the power. After the program start up, press



OTHER (OTHER).

🗐 Calendar	📇 Version
👤 Network	🐁 Maintenance
System	S Language
Speed	Calibrate

2. Press Speed .



3. Press OK

Main shaft adjusts its revolution speed automatically. Message complete will be displayed when setting is finished and it goes back to drive mode.

End of process.

### Maintenance mode

Maintenance mode consists of 9 i	tems as shown below.
Machine Test	Movement test, maintenance, and adjustment
Machine Setting	—Machine control setting
Memory All Clear	Initialization of design memory.
Main Program Update	
Machine Program Update	
Frame Position Entry-Registration	ion of coordinates for positioning sensor
Record	
Maintenance Register	
Other	—Other (This item is neither configured nor used.)
License Registration	Limited usable period
Replaced CONT Board	Machine Setting Navigation after exchanging CONT board (Main program Ver.*1.34~)

# How to enter maintenance mode

4-5-1

1. Turn on machine.



1. Press NEXT while pressing START/STOP button at the screen of the control box after booting the machine.





You can enter maintenance mode again by long key press

of (Menu) at the Drive screen after maintenance mode

is finished.

However, you cannot use the reentry method above once the machine is turned off and rebooted.

### Machine Test—Machine movement

Below operation will be moved solely. In some operations, actuator of motor will be moved, Keep hands and face away during movement for your own safety.

- #1 Needle Adjust : Input of Needle bar detect Potentiometer (Not used in HCH Plus)
- #2 Cutter Adjust : Action test of moving knife Open-CloseUse this function to adjust stop position of Moving knife.
- #3 Catcher Adjust : Action test of Thread catch hook This test is used to adjust stop position of Thread catch hook.
- #4 Keeper Test : Action test of Keeper solenoid ON-OFF This test is used to check action of Keeper.
- #5 Jump Solenoid Test : Movement test of jump device ON-OFF

This test is used to check movement of Jump device.

#6 Catcher Test : Movement test of thread catch hook IN-OUT

Use this test to check movement of Thread catch hook.

- #7 Cutter Test : Action test of moving knife Open-CloseUse this function to check opening-closing action ofMoving knife.
- #8 Clip Solenoid : Action test of clip type thread holder (Not used in HCH Plus)

This test is used to check movement of clip type thread holder.

- #9 Pointer Test : Action test of laser pointerThis test is used to check action of Laser pointer.
- #10 Fan Drive Test : Action test of cooling fan ON-OFF (Not used in HCH Plus)

Use this function to check movement of cooling fan.

- #11 Encoder Check : Input test of L point / C point timing With turning main shaft, you can use this function to check if L point signal, C point signal, and timing signal are correct or not.
- #12 Position Data Entry : Position Data Entry Confirm frame moving sensor

This test is used to check action of Frame moving sensor.

The Pulse motor will be un-locked when you activate the test, then you can move the embroidery frame to your desire position.

- #13 Position Data Entry : Confirm registration of frame position data (Not used in HCH Plus) You can use this function to check if Frame position data are entered correctly.
- #14 Shaft Drive Test : Main shaft control testYou can turn main shaft with pushing "Start" or "Jump" key of Needle bar section.


This function can be used for test run after maintenance work.


#15 Sequin test (Not used in HCH Plus)

This test is used to check or adjust of Sequin device.

### #16 Rotary Hook Adjust

This function can be used for [Adjustment of needle height] or [Adjustment of rotary hook timing].





100, 280 degrees

160, 340 degrees

[01]–[15]: Needle change

- [L point]: Main shaft will turn and set Needle bar position for [Adjustment of needle height] (L+5 degree).
- [Rotary hook]: Rotary hook will turn and stop every 120 degrees to access 3 fixing screws easier.
- [Ndl +1],[Ndl -1]: Needle bar moves to the left or right, then sets Needle bar position for [Adjustment of needle height] (L+5 degree).

#17 Needle Posi. Adjust

(Not used in HCH Plus)

## Machine Test—Machine movement

- 1. Enter maintenance mode in reference to [9-1 How to enter maintenance mode]
- 2. Press Machine Test .

# 1 Needle Adjust	# 6 Catcher Test	
# 2 Cutter Adjust	# 7 Cutter test	
# 3 Catcher Adjust	# 8 Clip Solenoid test	
# 4 Keeper Test	# 9 Pointer test	

3. Select desired number to be confirmed.

Page is switched by pressing

Selected item will be executed.

ESC
-

4. The screen returns to the [MACHINE TEST] screen by pressing ESC .

(Unnecessary to press ESC if the item completes automatically.)

# 1 Needle Adjust	# 6 Catcher Test	J
# 2 Cutter Adjust	# 7 Cutter test	Í.
# 3 Catcher Adjust	# 8 Clip Solenoid test	
# 4 Keeper Test	# 9 Pointer test	

5. Return to drive mode by pressing ESC and

126

Delete all the design memory.

Execute this function when occurring design breakage or impossibility of design input.


If abnormality is found after deleting all the data, replace LCD-CE board (or Core module) since the board might be broken.

#### <NOTE>


All the internal design memory will be deleted by initialization of design memory.

You have to be careful when initializing design memory.

- 1. Enter maintenance mode in reference to [9-1 How to enter maintenance mode ]
- 2. Press Memory All Clear .



3. Confirmation of free area and all delete will be started after pressing OK .



## Record—Operation data display

You can confirm history of operation.

Total number of stitch	: Total number of stitch used for embroidery so far
Error occurrence record	: Type of errors and its occurrence date for the last 32 errors
Occurrence record by error type	: Accumulated number of each error occurrence
Thread break history	: The number of thread break by needle bar

## Total number of stitch

[ MAINTENANCE ] / [ Record ]

THREAD

2. Press Record.

3. Press STITCH.

- 1. Enter maintenance mode in reference to [9-1 How to enter maintenance mode ]
- Selection menu of Clear Total Stitch will be opened when pressing CLEAR at Procedure 3.

Clear To	otal Stitch?
Cancel	ОК

- \* Total number of stitch is cleared after pressing OK and the screen shows one in the procedure 3. Total number of stitch is 0.
- \* If you do not prefer to clear it, press Cancel and the screen shows of the procedure 3 is shown
- 5. Return to drive mode by pressing ESC and



[ Stitch Record ]	
Total Stitch : O	
CLEAR	ESC

ERROR

The screen shows total number stitches used for

STITCH

ESC

4-5-4-1

# Record of Error occurrence

- 1. Enter maintenance mode in reference to [ 9-1 How to enter maintenance mode ]
- 2. Press Record .

	THREAD	ERROR	STITCH	
-	INKEAD	ERRUR	orrion	
			ESC	

### 3. Press ERROR.

Enable to confirm Record of error occurrence

1:			
2: 3: 4: 5: 6: 7: 8: 10:			
5:			
8:			
10:			
COUNT		1	
	753		
CLEAR		BACK	

\* Enable to confirm Occurrence date and error number of last

32 cases with

button.


Selection menu of Clear Error Record will be opened when pressing CLEAR.

Clear Error Recode ?	
Cancel OK	

- \* Error record is cleared by pressing OK and the screen of the procedure 3 is displayed.
- \* If you do not prefer to clear it, press Cancel and the screen of the procedure 3 is displayed..

# Number of occurrence in each error display

- 1. Enter maintenance mode in reference to [ 9-1 How to enter maintenance mode ]
- 2. Press Record .



### 3. Press ERROR.


You can confirm record of error occurrence.

2	Date	
3:		
1: 2: 3: 4: 5: 6: 7: 8: 9: 10:		
8: 9:		
10:		
COUNT		

### 4. Press COUNT .

You can confirm total number of occurrence in each error.

(E-000 to E-255 will be displayed )



\* You can confirm accumulated number for E-000 to E-255

	*	
with	•	

- \* The screen returns to the previous screen by pressing BACK.
  - Selection menu of Clear Error Total Count will be opened when pressing CLEAR and the screen of procedure 4 is displayed.

Clear Error Total Count ?
Cancel OK

- \* Error record is cleared by pressing OK and the screen of the procedure 4 is displayed.
- \* If you do not prefer to clear it, press Cancel and the screen of the procedure 4 is displayed.

### Thread break history


1. Enter maintenance mode in reference to [9-1 How to enter maintenance mode ]

### 2. Press Record .

THREAD	ERROR	STITCH	

### 3. Press THREAD.

You can confirm thread break history by needle bar.



• \*The screen returns to the previous screen by pressing BACK.

 Selection menu of Clear Thread Break Count will be opened when pressing CLEAR at the screen of procedure 3.

Clear Thread Break Count ?
Cancel OK

- \* Thread break history is cleared by pressing OK and the screen of the procedure 3 is displayed.
- \* If you do not prefer to clear it, press Cancel and the screen of the procedure 3 is displayed.

### Machine setting

1. Enter maintenance mode in reference to [ 4-4-1 How to enter maintenance mode ].

#### 2. Press Machine Setting



- 3. Select desired number and modify setting.
- · Setting values become default by pressing



- Page is switched by pressing
- 4. Press ESC button after modifying of setting number.




- 5. The screen returns to drive mode by pressing
- 6. Turn off power and on again before use a machine.

### Maintenance Register-Registration of machine maintenance date

Registration of machine maintenance date

When last maintenance date is registered, next regular maintenance date will be set automatically.


- 1. Enter maintenance mode in reference to [ 4-4-1 How to enter maintenance mode].
- 2. Press Maintenance Register.



3. Press Register.

The current date will be registered as last maintenance date.

When the machine runs more than 2000 hours (default setting) or 365 days are passed after last maintenance, the machine will display the message to have regular maintenance.



#### Registered date




- Pressing the RESET button delete the registered date.
- When the <u>Calender</u> button is pressed, you can set calendar of the machine.

- By pressing Days button, you can change the number of days for regular maintenance. (1 ~ 3,650 dsys)
- By pressing Hours button, you can change the number of running time for regular maintenance. (1 ~ 50,000 hours)

### 4. Press ESC.






End of process.

### Machine Setting Navigation after exchanging CONT board


After exchange CONT board, please activate [Machine Setting Navigation after exchanging CONT board] function. Then you can set necessary machine setting with one process.

4-4-3 Machine program updateand Main program update4-4-4 Initializing of machine speed


- Refer to [4-3-2 Preparation for program update] and prepare latest update programs.
- Insert USB memory that contains data for version up into insertion slot on the control box.
- 2. Refer to [4-4-1 How to enter Maintenance mode] and enter maintenance mode. The screen shows below:



3. Press Replaced CONT Board.



4. Press OK.




Г board	4-5-4-7
5. Pres	s Skip.
	2nd Step: Program Update
	01/
	ОК
6. Pres	s OK.
	Save the latest program to USB memory And set USB to USB slot on panel.
7. Press	OK.
	Do you want to update ?
	- Machine Program (Machine Board) -
	1. Machine Control : HCD2 HC   >> HCD2 HC   2. Frame Drive Data : CD1/H     >> CD1/H
	Cancel OK
8. When	the current machine program is older than latest
	on, pressOK.
	installation will be started.
	stall_HAPPY_App.exe } version 1.0.0
	ting Install New Language Data inguage >> Install
	current machine program is same or newer version,
press	Cancel.
	3rd Step: Select machine serial No. (for auto-machine setting)

### 9. Press OK .

10,000	-		

10. Enter the corresponding machine number.




11. Press OK.



12. Press OK

[Initializing of machine speed] will be started. Refer to [Initializing of machine speed] of [4-3-5 Setting of revolution] for more details.




13. Press OK.


The screen returns to the maintenance  $\mathsf{mode}_\circ$ 

Machine Test	Record
Machine Setting	Maintenance Register
Memory All Clear	Other
Main Program Update	License Registration
Machine Program Update	Repleced CONT Board
Frame Position Entry	( NAINTENANCE HODE

· End of process.




Electrical connection diagrams




Core module MX EP20140* Core module MX EP20140* CDD-CE-MX HCD8122* CITCUIt board HCD8122* TP-SW B10 Y-axis Motor I TP-SW B10 Y-axis Motor I B10 Y-axis Motor I B10 Y-axis Motor I B10 Y-axis Motor I B10 Y-axis Motor I Sensor I B10 Y-axis Motor I B10 Y-axis Motor I Sensor I B10 Y-axis Motor I B10 Y-axis Motor I Sensor I Contrell Poard HCU8105* Sensor HCU8105* Circuit board HCU8105* Sensor I Circuit board HCU8105* Sensor I Sensor		COTPowerLet avHCB7202*Co2CoableHCU7016*CO3SenserJobbleHCU7014*CO3SenserLet avHCU7012*CO3JobbleHCU7012*CO3JobbleHCU7012*CO5CobbleHC07012*CO5LableHC07017*CO5TimingcableCO7CrossLaserCO3LableHC07002*CO3LableHC07002*CO3JobbleHC07003*CO3JobbleHC07003*CO3JobbleHC07003*CO3LableHC07003*CO3LableHC07003*CO3LableHC07003*CO3LableHC07003*CO3LableHC07003*C03LableHC07003*C03LableHC07003*C03LableHC07003*C03LableHC07003*		(OPT I ON) (A21-2 Core module MX (A21-2 Cor	EPZ0139*
LCD-CE-MX HCDB122* HCDB122* B10 Y-axis Motor I circuit board HCDB116* B11 Keep B11 Keep B11 Keep Contributed Contributed B11 Keep B12 Photo sensor Circuit board HCDB103* B12 Photo sensor B12 Photo sensor Circuit board HCDB103* B12 Photo sensor Circuit board HCDB105* B13 Conserter B13 Conserter B15 Photo Sensor Circuit board HCDB105* Conserter Circuit board HCDB105* Photo Sensor Circuit board HCDB105* Circuit board Circuit board HCDB105* Circuit board Circuit board Circuit board HCDB105* Circuit board Circ		av le la verte la ver		Core module MX WLAN SMA cable Antenna 	EPZ0133#
TP-SW     HCD8116*     HCD8116*       circuit board     HCD8107*     B11       circuit board     HCJ8107*     B12       circuit board     HCJ8103*     B12       TC circuit     HCJ8103*     B12       TC circuit     HCJ8105*     B12       Trains     HCJ8105*     B13       timins     HCJ8105*     B14       timins     HCJ8106*     B15       circuit board     HCJ8106*     B15       circuit board     HCJ8106*     B15       circuit board     HCJ8104*     B15       circuit board     HCJ8104*     B15       circuit board     HCJ8104*     Connecter       circuit board     HCJ8104*     B15       Front Lighting HCB8116*     C.D. Emergency				SWA cable Antenna Antenna	EPZ0121#
board     HCJB107*     B12     Photo Sensor       it     HCJB103*     B13     Cross pointer       board     HCJB105*     B13     Cross pointer       board     HCJB106*     B14     Terminal       board     HCJB106*     B15     LCD unit       board     HCJB106*     B15     LCD unit       board     HCJB106*     B15     Memory card       board     HCJB106*     B16     Memory card				Anterna terna Anter	
TC circuit HCJB103* B13 Cross Pointer board timins HCJB105* B14 Cross Pointer B13 Cross Pointer B13 Cross Pointer B13 Cross Pointer B15 Connecter B15 Terminal Circuit board HCJB106* B15 TP unit Circuit board HCJB104* B15 Memory Card Circuit board Front Lighting HCJB116* C. Emergency Front					
Timins HCJ8105* B14 Terminal circuit board HCJ8106* B15 Connecter sensor HCJ8106* B15 LCD unit circuit board HCJ8104* B16 Memory card circuit board HCJ8116* C.C. Emergency			-cer209* -cur017* -cur002* -cur003* -cur003*		
sensor HCJ8106* BI5 LCD unit circuit board HCJ8106* BI5 LCD unit X-limit HCJ8104* BI6 Memory card circuit board Front lighting HCB8116* C Emergency					
BIB Memory card					
Emergency					
BIJ sw set			HCB7210#		   
BIB-) Input 110V type  HCB7957*					
DV type er unit	HCB7956*		     		
		CI2 KEEPER J cable HCJ7010*			
			HCB7216*	       	   
=		ole	HCJ7006#		   
	EPE0015* (UL type) EPE0013 (PSEtype)		HCD7252 <b>*</b>		   
			HCD7272*	+ ·	     
BO3 Noise Filter HCBT964* - Cable 2200 HCB 8603 & Sfuse Holder HCBT964* - Cable 2200 HCB	ЕРЕ 0017 (* (Ы- type)   НСВ7030 *   ЕРЕ 0018 (TIStype)	C17 BOX Cable2	HCD7273* -		   
B04 Power switch EPS0089*		e S	HCB7214 <b>*</b>		
B05) Power supply EPK0146*		C19 PD cable2 H	HCB7204*		
(BO6) PM-mo tor HCD7951 +		     			   
BOB Lower Thread HCBT962*		     	     		

# List of electrical connection diagrams

5-1




 $\supset$ 




### HCD81221 (Ser.No. ~1002003)

### LCD-CE-MX board Ass'y




CN No.	Function
X1	Core module I/F
X2	Core module I/F
X 5	7in LCD I/F
X 5_1	7in touch panel input
X5_2	10.4in touch panel input
X5_3	7in LCD backlight output
X5_4	10.4in LCD I/F
X 6_1	USB-A connector 1
X 6_2	USB-A connector 2
X 7	LAN
X 12	USB-B connector
X 13	AUX
X 14	SD card
X16	TP-SW board I/F
X90	CONT-** board I/F
OOtherther Other CN	Reserved


### HCD81222 (Ser.No. 1006001~) LCD-CE-MX board Ass'y



CN No.	Function
X1	Core module I/F
X2	Core module I/F
X 5	7in LCD I/F
X 5_1	7in touch panel input
X5_2	10.4in touch panel input
X5_3	7in LCD backlight output
X5_4	10.4in LCD I/F
X 6_1	USB-A connector 1
X 6_2	USB-A connector 2
X 7	LAN
X 12	USB-B connector
X 14	SD card
X16	TP-SW board I/F
X90	CONT-** board I/F




### HCD8116\* TP-switch board ass'y



CN No.	Function
CN1	Switch output, LED input


### HCJ8107\*

CONT-HP Circuit Board Ass'y




CN No.	Function
CN1	Input of 24V power source
CN2	Control box I/F
CN5	X position sensor I/F
CN6	Input of Thread catcher,
	Needle bar change,
	Thread cutting orig sensor
	Needle bar change
	potensionmeter
CN7	T/C sensor I/F
CN8	Inverter I/F
CN10	Bobbin winder motor
	output
CN12	Laser pointer output, Front
	LED output
CN14	Keeper solenoid output
CN15	Thread cutting solenoid
	output
CN16	Main switch remote output
CN21	Input of C point, L point,
	Main shaft angle
CN-M2	Needle bar change motor
	output
CN-M3	Output of Thread catch
	motor
CN-M4	Pressure foot motor output
CN-M6	Thread cutting motor
	output
CN-M9	X-Y motor output
CNE	AUX

#### HCJ8103\* TC SENSER Circuit Board Ass'y




CN No.	Function
CN1	CONT-** board I/F
CN2	Pointer output
CN3	FRONT LED output

#### HCJ8105\* TIMING Circuit Board Ass'y




CN No.	Function
CN1	Out put of L point, C point, angle sensor

#### HCJ8106\* SENSOR Circuit Board Ass'y




CN No.	Function
CN	Sensor output

#### HCB8116\* FRONT LED Circuit Board Ass'y




#### HCJ8104\*



#### X limit sensor board ass'y

\*When you receive some question from customer, please use this step for sold problem as sample.



## Trouble shooting(Electricity doesn't turn on)

Trouble	Factor	Cause of trouble and measure	Page
Electricity	Mechanical	1. Did fuse blow?	
doesn't turn on		1-1 If it did, replace it.	
		2. Check of defect on board.	
		2-1 Replace of CONT-** board ass'y.	
		2-2 Replace of LCD-CE-** board ass'y.	
		3. No problem in power supply?	
		3-1 Check and adjust the correct voltage.	4-1-3
		3-2 Try to replace power supply.	
		4. Check of Cable catching causes short-circuit.	
		4-1 Please insulate the cable after removing outer cover.	
		4-2 Replace of cable.	
		5. Confirm not getting power supply from same outlet with other embroidery	
		machine or other machines which contains motor.	
		5-1 Preferably only 1 embroidery machine should be connected with 1 outlet.	
		(Maximum 2-3machines)	
	Operator	1. Didn't press emergency switch?	
		1-1 Release lock.	(3-8)
	Environment	1. Is electricity in receptacle?	
		1-1 Supply power.	

Trouble	Factor	Cause of trouble and measure	Page
Thread break	Mechanical	1. Is needle drop unstable by vibration?	(2-5)
		1-1 Reconsider where to install the machine.	
		1-2 Move the machine to floor fully reinforced.	
		1-3 Use strong table to be able to endure vibration.	
		2. No burr or scratch in thread guide hole?	3-1-1
		2-1 Remove burr and scratch.	
		2-2 Replace of thread guide.	
		3. No problem in thread adjusting spring?	3-1-1
		3-1 Replace spring if it doesn't spring.	
		3-2 If weak or broken, replace it.	
		4. Does detecting roller make smooth turn?	
		4-1 Clean inside hole of bearing.	
		4-2 Correct so as for slit disc not to touch sensor.	4-2-2
		4-3 Correct so as for cable not to touch slit disc.	
		4-4 Check cable of TC 7 Board is unconnected	
		5. No problem in thread guide unit and thread tension ass'y?	3-1-1
		5-1 Remove burr and scratch if appeared.	
		5-2 Remove lints and clean.	
		6. Does disc on thread tension ass'y. turn smoothly?	3-1-1
		6-1 Remove lints and clean.	
		6-2 Replace	
		7. Is backlash between take-up lever and take-up crank roller not bigger?	
		7-1 Replace of take-up lever.	3-3-9
		8. No problem in needle holder?	
		8-1 Remove burr and scratch.	
		8-2 Make proper fixing. (direction)	3-1-2
		9. No burr and scratch on needle plate?	3-1-1
		9-1 Remove burr and scratch in needle hole.	
		9-2 Remove burr and scratch around needle hole on back of needle plate.	
		9-3 Replace it if not furbished.	
		9-4 If furbishing made needle hole wider, replace it.	
		10. No problem in pressure foot?	
		10-1 Remove burr and scratch.	3-1-1
		10-2 Correct bent.	3-1-1
		10-3 Adjust height.	3-2-10
		10-4 Replace of pressure foot.	3-2-11
		10-5 Replace of pressure foot drive cam.	3-2-9

# Trouble shooting(Thread break)

Trouble	Factor	Cause of trouble and measure	Page
Thread break	Mechanical	11. No problem in rotary hook?	3-1-1
		11-1 Clean it to remove lints.	(23-2)
		11-2 Furbish scratch.	
		11-3 If backlash of bobbin case holder and outer hook grows bigger, replace them.	3-5-1
		11-4 Replace.	
		12. No problem in rotary hook retainer?	
		12-1 Remove burr and scratch.	
		12-2 Adjust position.	3-5-2
		13. No problem in needle?	
		13-1 Fix it properly .	3-1-2
		13-2 Select proper size of needle to match thread thickness.	3-1-4
		13-3 If tip of needle is warped or bent, replace.	3-1-1
		13-4 Replace.	
		14. No problem in bobbin case?	
		14-1 Remove rust and scratch.	
		14-2 If thread guide spring is off, replace it.	
		15. No problem in bobbin?	
		15-1 Remove scratch (iron bobbin).	
		15-2 If distorted. replace it.	
		16. Is needle bar spring not broken?	
		16-1 Replace it.	3-3-7
		17. Does needle bar make smooth movement?	
		17-1 If bent, replace it.	3-3-7
		18. No backlash in moving head?	
		18-1 Adjust positioning roller shaft.	3-3-2
		19. Needle doesn't drop in the center of needle hole.	
		19-1 Adjust positioning plate and adjust needle drop back and forth.	3-3-4
		19-2 Adjust position of needle selection unit, then adjust needle drop right and left.	3-4-1
		20. Is the lowest needle position proper?	
		20-1 Adjust mechanical lowest needle position.	3-2-3
		20-2 Adjust electric lowest needle position.	4-2-1
		21. Is needle height proper?	
		21-1 Adjust as specified.	3-3-6
		22. Is rotary hook timing proper?	
		22-1 Adjust as specified.	3-5-1
		23. Is clearance between needle and rotary hook proper?	
		23-1 Adjust as specified.	3-5-1

Trouble	Factor	Cause of trouble and measure	Page
Thread break	Mechanical	24. Check tip of keeper hit the bobbin case.	
		24-1 Adjust it regularly.	3-6-12
		25. Is take-up lever timing proper ?	
		25-1 Adjust as specified.	3-2-8
		26. No problem in timing belt?	
		26-1 Adjust tension.	3-8-1
		26-2 If scratched or damaged, replace it.	3-8-2
		27. No problem in motor belt?	
		27-1 Adjust tension.	3-8-3
		27-2 If scratched or damaged, replace it.	3-8-4
		28. Is revolution setting proper?	(25-2)
		28-1 Make automatic speed setting.	4-4-4
	Operator	1. Operation is wrong (no proper [create] setting for sewing?)	
		1-1 Tell how to operate.	(15-1)
		2.Is pattern dwindled too much by pattern adjustment?	
		2-1 Adjust size so as to produce less thread break.	
		2-2 Use pattern edited again (density_ change).	
		3. Is thread tension properly set?	
		3-1 <upper thread=""> Considering sewing finish, set tension.</upper>	(8-1)
		3-2 <bobbin thread=""> Considering upper thread tension, set tension.</bobbin>	(4-5)
		5. Is bobbin put in bobbin case properly?	
		5-1 Viewing from front of bobbin case, set so that bobbin turns left-wise.	(4-5)
		6. Does thread cone stand properly?	(4-6)
		6-1 Keep thread from hitting felt.	
		6-2 Stand vertically.	
		7. Is passing of thread proper?	
		7-1 Pass thread properly.	(4-7)
		8. Is cloth properly stretched?	(6-2) (7-5
		8-1 No loosening and no too much tightening. Even tension in depth and width.	
		8-2 Texture should be even in direction of X and Y.	
		9. Is frame properly set?	(6-3) (7-6
		9-1 Frame should be put in positioning hole on tubular-frame.	
		9-2 No loosening of screw.	

# Trouble shooting(Thread break)

Trouble	Factor	Cause of trouble and measure	Page
Thread break	Operator	10. Is frame used to suit pattern size?	
		10-1 Use frame to suit pattern size.	
		11. When you dispose of thread (thread remains around rotary hook),	
		didn't you damage rotary hook, needle plate with scissors?	
		11-1 Tell to dispose of thread carefully.	
		11-2 Open needle plate to dispose of thread.	
		12. Didn't you neglect cleaning and oiling?	(23-2)
		12-1 Tell to always clean and use cleanly.	(23-1)
		12-2 Tell to oil regularly.	
	Thread &	1. Is thread used to suit needle size?	3-1-4
	cloth	1-1 Use thread to suit needle size.	(4-2)
		2. Is thread used to suit embroidery? (thread twist, tender thread).	3-1-3
		2-1 Don't use too strongly twisted thread.	(4-2)
		2-2 Twist of thread is to be left-wise.	
		2-3 Use tender thread.	
		2-4 Don't use thread with knot or uneven size.	
		3. Is thread properly wound aginst cone?	
		3-1 Use thread to be wound smoothly.	
		4. Isn't tip of cone warped or isn't thread caught in scratch?	
		4-1 Remove warp and scratch.	
		5. Don't use thread left for a long period? (inferior thread).	
		5-1 Don't buy thread more than you use.	
		5-2 Tell not to store thread for a long period.	
		5-3 Tell how to store. (direct sunshine. humidity dust etc.)	
		6. Isn't poor unwoven cloth used? Is number of sheets used proper?	
	Environment	1. Is strength of table and floor enough?	(2-5)
		1-1 Reconsider place to install the machine.	
		1-2 Move the machine to place where floor is strong enough.	
		1-3 Use table with strength endurable against vibration.	
		2 Are room temperature and humidity proper against thread?	(23-1)
		2-1 It is desirable to install air conditioner to keep temperature and humidity	
		in a certain level.	
		3. Doesn't embroidery machine receive direct sunlight? (cause of inferior thread)	
		3-1 See not to expose to sunlight (spread curtain)	(2-6)

Trouble	Factor	Cause of trouble and measure	Page
Thread break	Environment	4. Is there something that produce steam, wasted cotton, dust around.	
		the embroidery machine?	
		5-1 Keep the embroidery machine off those things.	(2-6)
		5. Does thread go out of control by taking wind from outside or heater etc.?	
		6-1 Keep the embroidery machine off such wind.	(2-6)
		6-2 Move the embroidery machine to proper place.	
	Pattern	1. Does thread break occur repeatedly at same place in design?	
		1-1 Check pattern to modify punching.	
		2. Is it too narrow between stitches?	
		2-1 Check pattern to modify punching.	
		2-2 Setting of [create] menu. (Stitch sweep)	(10-3)
		3. Too many empty stitches?	
		3-1 Make [create] setting. (this setting doesn't read empty stitches)	(10-3)
	Others	1. Using spray paste (adhesive material)	
		1-1 Clean around rotary hook.	3-1-2
		1-2 Replace or clean needle.	(23-2)
		1-3 Use this paste at a given place and never use in front or back of	(4-1)
		the embroidery machine.	

## Trouble shooting(Erroneous thread cut)

Trouble	Factor	Cause of trouble and measure	Page
Erroneous	Mechanical		
thread cut		2. Isn't rubbing of fixed knife and moving knife weak?	
(E-190)		2-1 Adjust to be able to rub properly.	3-6-8
(E-193)		3. Does moving knife make smooth move?	(23-3)
		3-1 Check if rubbing of moving knife and fixed knife is not too strong.	3-6-8
		4. Check Displace of moving knife.	
		4-1 Adjust of moving knife position.	3-6-9
		5. Check defacement of moving knife or fixed knife.	
		5-1 If possible, furnish with file.	
		5-2 Replace	3-6-6
			3-6-7
		6. No backlash in up and down direction of knife drive shaft?	3-6-8
		6-1 Check no loosening of screw on moving knife.	
		6-2 Check no loosening of screw on knife drive shaft.	
		7. No backlash in fixed knife?	3-6-8
		7-1 Check no loosening of screw on fixed knife.	
		8. Does thread cut pulse motor work properly?	
		8-1 Check cable.	
		8-2 If trouble found in CONT-** board ass'y, replace.	
		8-3 If trouble found in thread cut pulse motor, replace.	
		9. Is number of revolution proper at time of thread cut?	
		9-1 Make automatic speed setting.	(25-2)
		9-2 If trouble in CONT-** board, LCD-CE-** board ass'y, replace.	4-4-4
		10. Is there no skipped stitch?	
		10-1 Adjust needle depth.	3-3-6
		10-2 Adjust clearance between needle and rotary hook.	3-5-1
		10-3 Is height of pressure foot proper?	3-2-10
		10-4 Is rotary hook timing proper?	3-5-1
		10-5 Is relation between needle and thread proper?	

(

## Trouble shooting(Erroneous thread cut)

Trouble	Factor	Cause of trouble and measure	Page
Erroneous	Mechanical	11. Check the needle bar moves up and down during thread cut.	
thread cut		11-1 Adjust position of jump device.	3-2-5
(E-190)		11-2 Replace needle bar cushion.	3-3-7
(E-193)		11-3 Replace needle bar driver.	3-2-4
		12. Is position of keeper proper?	
		12-1 Adjust the fixed position regularly.	3-6-12
		13. Check the movement of keeper goes smoothly.	
		13-1 Readjust if it is not smooth.	3-6-12
	Operator	1. No negligence in cleaning thread cut device?	(23-2)
		1-1 Tell to clean regularly.	
		# It's desirable to prepare brush with soft hair and air gun.	
		2. Is timing of thread tension proper?	
		2-1 <upper thread=""> Considering sewing finish, set tension.</upper>	(8-1)
		2-2 <bobbin thread=""> Considering upper thread tension, set tension.</bobbin>	(4-5)
	Environment	1. Are power and voltage rated and stable?	
		1-1 Supply rated voltage.	
	Thread &	1. Is twist of thread too strong?	
	cloth	1-1 Use thread with proper twist.	
		2. No skipping by use of lots of paste?	
		2-1 Use small amount of paste.	
		2-2 Remove paste stuck to needle.	

## Trouble shooting(Off-registration of pattern)

Trouble	Factor	Cause of trouble and measure	Page
Off-registration		1. Does frame move smoothly?	
of pattern		1-1 Avoid curling of thread and cloth.	
<b>p</b>		1-2 Reinstall of outer cover in case of touch with outer cover.	2-1
		1-3 Adjust with no clearance between Arm and Connecting plate B.	
		2. Is bound of frame base too big?	(6-1b)
		2-1 Fix frame base between bearing and base without gap.	
		3. Is carriage belt tension proper?	3-7-1
		3-1 Adjust all belts as specified.	3-7-3
			3-7-3
		4. No loosening of screws on carriage drive?	
		4-1 Check screw. If loosened, tighten firmly.	
		5. No lints or dust around idler pulley on carriage?	
		5-1 Clean	
		6. No damage in carriage belt?	3-7-2
		6-1 If damaged, replace.	3-7-4
		7. No backlash of back and forth in moving head?	
		7-1 Adjust positioning roller shaft to remove backlash back and forth.	3-3-2
		8. Is height of pressure foot proper?	
		8-1 Adjust as specified.	3-2-10
		9. No problem in motion of pulse motor for X/Y carriage ?	
		9-1 Check wiring. If screw got loosened, tighten more.	
		9-2 After 9-1, still problem, then replace.	
		10. No problem in motion of CONT-** board ass'y ?	
		10-1 Check wiring. If screw got loosened, tighten more.	
		10-2 After 10-1, still problem, then replace.	
		11. Does't other frame than Happy's genuine one used?	
		11-1 If frame is too heavy, don't use it.	
		11-2 If setting is not proper, set it so as not to move.	
		12. No problem in LCD-CE-** board ass'y ?	
		12-1 Try to initialize.	4-1-1
		12-2 Replace of LCD-CE-** board ass'y.	
		13. Is number of revolution proper?	(25-2)
		13-1 Make automatic speed setting.	4-4-4
		14. Not affected by noise?	
		14-1 Don't use the machine near where noise is generated.	
	Operator	1. Is setting of frame correct?	(6-3) (7-6
	212.000	1-1 Frame should be put in positioning hole on tubular frame.	
		1-2 Set so as for screw not to loosen.	

## Trouble shooting(Off-registration of pattern)

Trouble	Factor	Cause of trouble and measure	Page
Off-registration	Operator	2. Is cloth properly stretched.	(6-2) (7-5)
of pattern		2-1 Stretch properly.	
		3. Is thread tension proper?	(4-5) (8-1)
		3-1 Observing sewing rhythm, set thread tension properly.	
		4. Was the machine left for a long time in middle of sewing?	
		4-1 Try to finish sewing as soon as possible.	
	Environment	1. Is strength of table and floor enough?	(2-5)
		1-1 Check where to place the machine again.	
		1-2 Move to where floor is strong enough.	
		1-3 Use strong table to be able to endure vibration.	
		2. No problem in CONT-** board ass'y by low power and voltage (variation)?	
		2-1 Supply rated voltage.	
		2-2 Use transformer.	
		2-3 Use stabilizer.	
		3. Is there no place where noise is generated near the machine?	
		3-1 Don't use the machine near where noise is generated.	
		4. Doesn't drive frame hit obstacle?	(2-5)
		4-1 Remove obstacle.	
		4-2 When useing cap frame, see not to hit table.	(2-6)
	Thread &	1. Not using shrinkable cloth?	(4-3)
	cloth	1-1 Use backing paper (consider number of sheets to use).	
		2. Isn't breakable cloth is used by thread tightening?	(4-3)
		2-1 Use backing paper (consider number of sheets to use).	
		3. Is proper backing paper used?	(4-3)
		3-1 Use backing paper to match cloth.	
		4. Isn't cloth (embroidery) too heavy?	
		4-1 Don't use extremely heavy cloth.	
	Pattern	1. Pattern data may be destroyed.	(5-4) (5-5)
		1-1 Read again.	
		1-2 Let new pattern read.	
		2. Memory pattern was destroyed.	(5-4) (5-6)
		2-1 Let new pattern read.	
		3. No problem in USB memory ?	
		3-1 Initialize and read again.	
1		3-2 Prepare new USB memory.	

7-2-4

#### Trouble shooting(Upper thread comes off from needle hole)

7-2-5

Trouble	Factor	Cause of trouble and measure	Page
Upper thread	Mechanical	1. Is keeper in motion?	
comes off		1-1 Check if cable was cut or there is something unusual.	
from needle		1-2 In case solenoid is in trouble, replace.	3-6-11
hole		1-3 In case CONT-** board ass'y is in trouble, replace.	
		2. Is keeper put in right place?	
		2-1 Put it as specified.	3-6-12
		2-2 Modify bent of keeper.	
		2-3 Adjust it again if movement is not smooth.	
		3. Is magic-tape on thread catch holder not worn?	
		3-1 Replace magic-tape.	3-3-14
		4. Does bobbin thread holder hold bobbin thread?	
		4-1 Adjust pressure when contacting moving knife.	3-6-10
		4-2 In case bobbin thread holder is in trouble, replace.	
		4-3 Clean bobbin thread holder.	
		5. No error in thread cut (2 threads cut)?	
		5-2 Position moving knife as specified.	3-6-9
		5-3 Check and polish burr or scratch on moving knife.	
		5-4 In case moving knife is in trouble, replace.	3-6-6
		6. Are clearance between needle and rotary point and needle height are proper?	
		6-1 Adjust clearance between needle and rotary hook as specified.	3-5-1
		6-2 Adjust needle depth.	3-3-6
		7. Doesn't thread catch hook cut upper thread?	
		7-1 Polish burr on hook.	
		7-2 In case hook is in trouble, replace.	
		8. Does thread catch hook hold upper thread?	
		8-1 Check if cable was cut or there is something unusual.	
		8-2 In case pulse motor is in trouble, replace.	
		8-3 Adjust fixing position.	3-2-18
		8-4 If hook is bent, modify.	
		8-5 In case hook is in trouble, replace.	
		8-6 In case CONT-** board ass'y is in trouble, replace.	
		9. Check tension of thread adjusting spring is too weak.	
		9-1 Adjust of tension.	3-3-11

## Trouble shooting(Upper thread comes off from needle hole)

7-2-5
1-2-5

Trouble	Factor	Cause of trouble and measure	Page
Upper thread	Mechanical	10.Check the needle bar moves when start sewing.	
comes off		10-1 Adjust position to fix jump device.	3-2-5
from needle		10-2 Replace needle bar driver.	3-2-4
hole		11. Is number of revolution proper when sewing started?	(25-2)
		11-1 Make automatic speed setting.	4-3-5
		12.Is height of pressure foot proper?	
		12-1 Adjust as specified.	3-2-10
	Operator	1. Isn't thread tension too strong?	(4-5) (8-1
		1-1 Weaken tension not to cause trouble in sewing rhythm.	
		2. Keen in cleaning thread cut device?	(23-3)
		2-1 Clean bobbin thread holder regularly.	
		3. Is setting of bobbin thread proper?	(4-5)
		3-1 Pass thread on bobbin thread guide surely.	
		4. Is bobbin thread properly wound?	(4-4) (4-5)
		4-2 Pull out bobbin thread to check if it comes out smoothly.	
		5. Is upper thread properly passed?	(4-6) (4-7
		5-1 Pass properly again.	
		6. Does thread cone stand properly?	(4-6)
		6-1 Keep thread from hitting felt.	
		6-2 Stand vertically.	
		7. Is [create] properly set?	(15-1)
		7-1 Select longer setting of upper thread length.	
		7-3 Select start lock stitch [effective].	
	Thread &	1. Is thread used to suit embroidery? (thread twist, tender thread).	3-1-3
	Cloth	1-1 Don't use too strongly twisted thread.	
		1-2 Twist of thread is to be left-wise.	
		1-3 Use tender thread.	
		1-4 Don't use thread with knot or uneven size.	
	Environment		(2-6)
		1-1 Keep the embroidery machine off from wind.	(= =)
		2. Is voltage of power as rated and stable?	
		2-1 Supply rated voltage.	
	Pattern	1. Is there stop sewing stitch for start sewing?	
		י די אי היביב אנטף אבאוווע אווטר אנמון אבאוווע (	1
	1 attern	1-1 Modify pattern. 1-2 Set lock stitch function.	(15-5)

# Trouble shooting(Upper thread remains)

Trouble	Factor	Cause of trouble and measure	Page
Upper thread	Mechanical	1. Upper thread is difficult to come out of keeper at time of thread cut (bent or warp etc.).	
remains		1-1 Modify bent or warp.	
		1-2 Replace keeper.	
		2. Keeper doesn't return properly at time of thread cut.	
		2-1 Modify bent of keeper.	
		2-2 Adjust position to fix.	3-6-12
		2-3 Adjust it again if movement is not smooth.	
		3. Upper thread does not come off from magic tape of thread holder.	
		3-1 Insert something(Thickness 0.1-0.2mm) into holder then move it right and	
		left to put magic tape in order.	
		3-2 Replacement of magic tape.	3-3-14
		4. Doesn't thread catch hook cut upper thread?	
		4-1 Polish burr on hook.	
		4-2 In case hook is in trouble, replace.	
	Operator	1. Setting of thread tension is weak.	(4-5) (8-1)
		1-1 Strengthen so as not to cause trouble in sewing rhythm.	
		2. Is [create] properly set?	(15-1)
		2-1 Select length of upper thread [standard].	
	Thread &	1. Using hard cloth make thread difficult to go through.	
	cloth	1-1 Select needle and thread.	3-1-4
		2. Using thick cloth make thread difficult to go through.	
		2-1 Select needle and thread.	3-1-4
		3. Is thread used to suit embroidery? (thread twist, tender thread).	3-1-3
		3-1 Don't use too strongly twisted thread.	(4-2)
		3-2 Twist of thread is to be left-wise.	
		3-3 Use tender thread.	
		3-4 Don't use thread with knot or uneven size.	

#### Trouble shooting(Malfunction of thread break detection)

Trouble	Factor	Cause of trouble and measure	Page
Malfunction of	Mechanical	1. Trouble in turning detection roller.	
thread break		1-1 Clean roller shaft holder.	
detection		1-2 Check if slit disc doesn't contacts sensor.	4-2-2
(empty		1-3 Clean sensor if dust gets stuck.	
detection)		1-4 Check if cord doesn't contacts slit disc.	
		1-5 Check Disconnection of cable.	
		2. Check circuit board.	
		2-1 Replace of LCD-CE-** board ass'y.	4-1-1
		2-2 Replace of TC 7 board.	
		3. Sometimes needle bar doesn't work when start sewing.	
		3-1 Replace if cushion has been decrepit.	
		3-2 Replace of needle bar driver.	3-2-4
		3-3 Adjust of jump device position.	3-2-5
		3-5 Replace of Jump device.	
		3-6 Adjust position of Photo interrupter on Thread catcher.	
	Operator	1. No thread is passed through detecting roller.	
	Operator	1-1 Pass thread properly.	(4-7)
		2. Is thread tension proper?	(+-7)
		2-1 Observing sewing rhythm, adjust thread tension properly.	(4-5) (8-1)
		3. Is proper detection sensitivity of thread cut selected?	(5-1)
		3-1 Select detection sensitivity according to sewing condition of thread and cloth etc.	(0-1)
	Environment	1. Is there any device to yield lints etc. around the embroidery.	
	Environment	1-1 Keep it off the embroidery machine.	
		1-2 Move the embroidery machine to other place.	
		2. Doesn't thread go beyond control by wind? (thread comes off from needle hole by loosing)	(2-6)
		2-1 Keep thread off wind.	(2 0)
		2-2 Move the embroidery machine to other place.	
	Thread &	1. Isn't silicone agent used on thread?	
	Cloth	(Thread slips at detecting roller part due to adhere of silicone.)	
		1-1 Clean silicone agent attached to detecting roller groove.	

## Trouble shooting(Malfunction of thread break detection)

Trouble	Factor	Cause of trouble and measure	Page
Malfunction of	Mechanical	1. Check circuit board.	
thread break		1-1 Replace of CONT-** board ass'y.	
detection		1-2 Replace of TC 7 board.	
(not detected)	Operator	1. Is thread tension proper?	
(slow detected)		1-1 Observing sewing rhythm, adjust to proper thread tension.	(4-5) (8-1)
		(Adjust it little bits stronger.)	
		2. Is proper detecting sensitivity of thread cut selected?	(15-1)
		2-1 In case of being not detected, make [thread cut detection] setting to [yes].	
		2-2 Select detection sensitivity of thread cut according to sewing condition of thread and cloth etc.	

## Trouble shooting(Suspension of upper shaft)

Trouble	Factor	Cause of trouble and measure	Page
Suspension	Mechanical	1. Upper thread twine round rotary hook or rotary hook retainer.	
of main shaft		1-1 Get rid of it.	
(E-18)		2. Check return of keeper goes smooth. (when start sewing.)	
(E-51)		2-1Adjust it regularly.	3-6-12
(E-52)		3. Check upper thread is sticking at thread guide part of bobbin case.	
		3-1 Get rid of it.	
		3-2 Do not use of bobbin case in which thread guide is coiled type. (use standard type)	
		4. Out of Needle bar block B from pressure foot block.	
		4-1 Insert needle bar block B into pressure foot block by doing	
		needle bar change manually.	
		5. Defect on drive part of pressure foot.	
		5-1 Modify Pin B and hit part of link A and B by sand paper.	
		5-2 Replace of pressure foot block ass'y and link ass'y.	3-2-13
		6. Effect by breakage of parts.	
		6-1 Repair broken place.	
		7. No damage in electric parts?	
		7-1 Replace of CONT-** board ass'y.	
		7-2 Replace of Timing Board.	
		8. Trouble of software in LCD-CE-** board ass'y.	(25-1)
		8-1 Initialize, then make automatic speed setting.	(25-2)
			4-4-4
		9. Trouble in control of number of revolution.	(25-2)
		9-1 Make automatic speed setting.	4-4-4
-	Operator	1. Isn't foreign stuff such as thread or cloth caught in where revolution is driven.	
		1-1 Get rid of foreign stuff.	
		1-2 Stretch properly.	(6-2) (7-5
		2. Isn't thread tension too strong (stop at time of action of thread cut)?	(4-5) (8-1
		2-1 Weaken tension so as not to cause trouble in sewing rhythm.	
		3. Check condition of lubrication.	
		3-1 Lubricate (refer to message)	(23-1)
	Environment	1. Check adequate level of voltage.	
		1-1 Supply rated voltage.	
		100V – 115V -10V / +15V	
		200V – 230V -10V / +10V	

(

## Trouble shooting(Malfunction of needle bar change)

Trouble	Factor	Cause of trouble and measure	Page
Head does not	Mechanical	1. Check lint or cloth is seized between Lower Moving rail and Bearing.	
move		1-1 Remove seized lint or cloth.	
(E-021)		2. Check lint or waste is seized in gap of Moving Cam.	
(E-022)		2-1 Remove seized lint or waste.	
		3. Effect by breakage of parts.	
		3-1 Repair broken place.	
	Operator	1. Check Stopper of Moving Head is removed.	
		1-1 Remove Stopper.	
Uncontrollable	Mechanical	1. No problem in sensor circuit board ?	
Move		1-1 Clean dust attached to sensor.	
(E-024)		1-2 Replace sensor circuit board.	4-2-1
(E-025)		2. Needle number is not exactly recognized.	
		3-1 Check position of Photo interrupter on Needle bar change unit.	4-2-3
		3. Breakage of Pulse Motor .	
		4-1 Replace Pulse Motor.	

## Trouble shooting(Defect on Thread catcher)

Trouble	Factor	Cause of trouble and measure	Page
does not catch	Mechanical	1. Thead catcher does not extend hook sufficiently.	
thread		1-1 Adjust position of Thread catcher .	3-2-18
		1-2 Adjust position of Thread holder.	3-3-13
		2. Excessive distance between Hook and tip of Needle.	
		2-1 Adjust position of Thread catcher.	3-2-18
		2-2 Adjust position of Thread holder.	3-3-13
Hook of Thread	Mechanical	1. Check Hook of Thread catcher bent or not.	
catcher does not		1-1 Repair bent Hook.	
extend		1-2 Replace Hook.	
		2. Check position of Thread catcher is proper.	
		2-1 Adjust	3-2-18
		3. Check position of Thread holder is proper.	
		3-1 Adjust	3-3-13
		4. Check Thread catcher.	
		4-1 Check cable is securely connected.	
		4-2 Replace Pulse Motor with trouble.	
		5. Check CONT-** board ass'y.	
		5-1 Replace CONT-** board ass'y.	
Hook hits or	Mechanical	1. Check Hook is bent or not.	
catches Needle		1-1 Repair bent Hook.	
(E-193)		1-2 Replace Hook.	
		2. Check position of Thread catcher is proper.	
		2-1 Adjust	3-2-18
		3. Check position of Thread holder is proper.	
		3-1 Adjust	3-3-13
	Operator	1. Check if Needle is securely set.	
		1-1 Set Needle properly.	(4-1)
			3-1-2
Constant display	Mechanical	1. Trouble of Photo interrupter for Thread catcher.	
of E-193		1-1 Replace Photo interrupter.	

## Trouble shooting(Others / Mechanical)

Trouble	Factor	Cause of trouble and measure	Page
Needle Breakage	Mechanical	1. Check Needle is not bent.	
		1-1 Replace bent Needle.	3-1-2
		2. Check Moving Head set securely.	
		2-1 Adjust Positioning Roller Shaft.	3-3-2
		3. Secure adequate distance between Needle and Rotary Hook.	
		3-1 Adjust distance properly.	3-5-1
	Operator	1. Is thread method in proper way?	(4-6)
		1-1 Threading again in a proper way.	(4-7)
		2. Check upper thread comes in a smooth way. (Thread stand, Thread tension point, double back etc)	
		2-1 Adjust place be caught in.	
		3. Check whether fabric is fixed firmly or not.	
		3-1 Hooping fabric firmly again.	(6-2) (7-5)
Defect of pressure	Mechanical	1. Check whether pressure foot and thread catcher holder touch each other or not.	
foot movement		1-1 Adjust installment position of thread catch holder.	3-3-13
		1-2 In case pressure foot is fixed at an angle, fix it vertically again.	
		2. Defect of censor circuit board for Pressure foot.	
		2-1 Replace of censor circuit board.	
Abnormal noise	Mechanical	1. By defect of cover installation. (Pressure foot drive, Carriage etc)	
		2-1 Take care of insert condition, clearance etc and fix again.	
		2. By lack of oil inside rotary hook.	(23-1)
		2-1 Refuel	3-5-1
		2-2 Replace of rotary hook	
		3. Touching of cap switch bracket on X carriage to cover.	
		3-1 Adjust bend of bracket.	
Big noise	Mechanical	1. Gap between pressure foot block and needle bar boss B.	
		1-1 Replace of pressure foot block.	3-2-13
		2. Bearing gap of take up crank ass'y.	
		2-1 Adjust bearing.	3-2-7
		2-2 Replace of bearing.	
		3. Gap between take up lever ass'y and take up clank ass'y.	
		3-1 Replace of take up lever ass'y.	3-3-9
		3-2 Replace of take up lever crank ass'y	

## Trouble shooting(Others / Electric)

Trouble	Factor	Cause of trouble and measure	Page
Frame overrun	Mechanical	1. Interference between censor circuit board and douser.	
		1-1 Position adjustment of douser.	
		1-2 Replace of censor circuit board.	
		2. Check whether cable has problem or not.	
		2-1 Replace in case damage exists.	
		2-2 Insert connector again.	
		3. Check CONT-** board ass'y.	
		3-1 Replace of CONT-P board ass'y.	
Key on control box	Mechanical	1. When removing panel in replacing circuit board , due to poor cable bundling,	
can not be pressed		circuit board being pushed from inside.	
down and returned		1-1 Bundle cable again	
Defect of LCD	Mechanical	1. Check LCD .	
		1-1 Replace of LCD	4-1-1
		2. Inadequate condition of cable insertion	
		2-1 Insert to the back firmly.	
		3. Check whether LCD-CE-** board ass'y is out of order or not.	
		3-1 Replace of LCD-CE-** board ass'y.	4-1-1
Defect of data	Mechanical	1. Check whether cable (USB or LAN) is insert firmly between PC and Machine.	
communication		1-1 Insert again	
(E-90)		2. Check whether PC has problem or not.	
(E-91)		2-1 Affirm whether there is problem or not.	
		3. Check whether LCD-CE-** board ass'y is out of order or not.	
		3-1 Replace of LCD-CE-** board ass'y .	4-1-1
Pattern disappears	Mechanical	1. Trouble in back-up battery	
/ Watch doesn't		1-1 Replace battery on LCD-CE-** board ass'y.	4-1-2
indicate time		2. No trouble in memory tip on LCD-CE-** board ass'y ?	
		2-1 Conduct [memory all clear] in maintenance mode.	4-5-3
		2-2 If above measure doesn't solve the trouble, replace LCD-CE-** board ass'y.	

Error message will be displayed if error occurs during machine startup.

After confirming contents, press button [OK] on control box to release error, then restore in accordance with measure in this list.

Message	Error	Measure
Error The information of the EMB machine does not match the Control Box's.	Exchanged control box or CONT board does not match for the	When only control box has been exchanged, open the menu of [4-4-4-5 Setup — Machine setting] and just close without any amendment.
ОК	installed data of [Machine setting].	When CONT board has been exchanged, follow the procedure of [4-4-4-7 Machine Setting Navigation after exchanging CONT board].
S Frame data do not match	Installed frame drive data in the machine does not match.	Check setting contents of [Machine setting] by referring [4-4-4-5 Setup—Machine setting], then follow the procedure [4-3-3Machine program update].

#### Error and measure

When trouble occurred while the machine is running, error number and error item will be displayed. After confirming contents,

No.	Message	Error	Measure	Page
001	Circuit board	Trouble detected in control circuit board.	(1)Turn power off once and turn on again.	
			(2)If recurred, replace LCD-CE-** board ass'y.	
004	System memory	Trouble in system memory.	Replace LCD-CE-** board ass'y.	
018	Main shaft	Suspension of main shaft in mid way.	(1)Check if trouble found between main shaft	
			and drive. If trouble found, restore.	(25-1)
			(2)If recurred, find cause and fix.	(25-2)
			(3)Make automatic speed setting again. Initializin	9
020	Needle detect	Needle position not detected.	(1)Turn needle selection cam by hand to set to	
		Trouble in stop position of needle	regular position.	
		selection unit.	(2)Fix needle selection related mechanical trouble.	
			(3)Replace sensor circuit board.	4-2-3
021	Needle move	Suspension of needle selection motor	(1)Turn needle selection cam by hand to set to	
022		in mid way.	regular position.	
		Trouble in take-up lever hinders.	(2)Fix needle selection related and take up lever	
		Trouble in sensor circuit board	related troubles.	
			(3)Replace sensor circuit board.	4-2-3
024	Needle center	Stop position of needle bar is off center	(1)Turn needle selection cam by hand to set to	
			regular position.	
			(2)If trouble occurs repeatedly, fix mechanical	
			trouble in needle selection & its vicinity.	
025	Needle over	Specified needle number went beyond	Adjust position of needle selection cam and	
		needle number of the machine.	Photo interrupter on Needle bar change unit.	5-5-1
026	Needle differ	As needle number differed from memory	(1)Turn power off once and turn on again.	
		when power turned on, it was renewed.	(2)Let the machine recognize needle number.	5-5-1

press key [ENT.] on control box to release error, then restore in accordance with measure in this list.

#### Error and measure

No.	message	Error	measure	page
030	Slow mismatch	Inadequate adjustment of number of	(1)Make automatic speed setting. Initializing	
		low speed revolution.	(2)If not solved even after speed adjustment,	(25-1)
		Low speed revolution doesn't come	replace CONT-P board ass'y	(25-2)
		below 100rpm.		
050	C point	Main shaft stops off its position.	Turn main shaft to plus direction to set to C point.	(24-4)
051	L sensor	Poor lowest needle position sensor	(1)If photo sensor is stained, clean.	4-2-1
		on timing detecting circuit board.	(2)Adjust timing.	(25-1)
		Damage in timing detecting circuit	(3)Replace main shaft timing circuit board.	(25-2)
		board, stained photo sensor, poor	(4) Initializing, Initializing of machine speed	
		adjustment of slit disc.		
052	C sensor	Damage in color change point		
		sensor on timing circuit board.		
		Damage in timing detecting circuit		
		board, stained photo sensor, poor		
		adjustment of slit disc.		
060	X limit	Drive frame went beyond limits in X direction.	(1)Move drive frame back to limits with move key.	
061	Y limit	Drive frame went beyond limits in Y direction.	(2)Correct pattern size and setting contents.	
090	Miss reception	Error occurred when transmitting data.	Let the machine read pattern data from first.	(5-4)(5-6)
091	No send	Data is not put in for over 10 seconds.	Let the machine read data from first.	(5-4)(5-6)
103	Data format	The machine can't judge format of	(1)Check format of pattern data.	(5-6)
		pattern data.	(2)By setting reading of pattern data,	(10-3)
			set format properly.	
104	Miss function	Timing to read pattern data doesn't	Read pattern data again from the first.	(5-4)
		conform.		(5-6)
105	Dual function	One stitch data has more than 2	(1)Read pattern data again from the first.	(5-6)
		functions.	(2)Check and modify the design data if there is wrong.	(10-3)
108	Improper read	While reading pattern data, there	Read pattern data again from the first.	(5-4)
		accrued error in internal processing.		(5-6)
110	Memory full	While reading pattern data, memory	Delete unnecessary patterns and read from	(5-5)(5-B)
		exceeded its capacity.	the outset.	(23-1)

#### Error and measure

No.	message	Error	measure	page
111	Change over	While reading pattern data, the	(1)Modify pattern data and reduce frequency of color	
		frequency of color change (color No.)	change of one pattern to less than 250 times.	
		exceeded 250 times.	(2)Divide pattern data and reduce frequency of color	
			change of one pattern to less than 250 times.	
112	Data error	Pattern data of pattern to be	(1)Read pattern data again from the first.	(5-4)(5-6)
		embroidered is damaged.	(2)Read pattern data again if you have	
			a backup data.	
114	ld over	The number of pattern in memory has	Delete unnecessary patterns and read.	(5-5)
		reached maximum of 250.		(5-B)
118	Trace data over	The stitch number counts over 1024	Set Embroidery area of pattern data within	
		stitches during preparing Trace data.	2m(X) x 2m(Y).	
120	Memory error	It became impossible to retain contents	(1)Replace the battery for memory backup.	4-1-2
		of memory.	(2)Replace the LCD-CE-** board ass'y if recurs	
		(Ser.No. ~1002003)	even change the battery.	
130	Card error	Incapable of disposing of USB memory	(1)Turn off power source once and turn it on again.	
		continuously.	(2)USB Memory reading processor may defective.	
			Replace the circuit board.	
131	Card no ready	USB Memory is not set.	Check if USB memory is properly set.	(5-5)
133	Bad card	USB Memory is not proper or broken.	(1)USB Memory might be not readable with the machine.	(5-5)
			Prepare readable USB memory for the machine.	
			(2)USB Memory card might be defective.	
			Prepare another memory card which is not defective.	
			(3)Initialize the USB memory if it is not initialized.	
141	Not found name	Designated pattern is not found.	USB Memory might be not readable with the machine.	(5-5)
			Prepare readable USB memory for the machine.	
190	Cut blade	Thread cut knife is not at stop position.	(1)Restore the moving knife to stop position.	(24-5)
			(2)Modify the adjustment if the problem repeats.	
193	Catcher	Thread catch hook is not in its	(1)Check if mistake is found in thread cut.	(24-6)
		stop position.	If found, cut thread and move thread catch	
			hook to proper position.	
			(2)Adjust and correct trouble that hinders motion	
			of thread catch hook.	


		Tables for Timing/Adjustment value	
Take-up lever timing		10 degrees	
Rotary hook timing		25 degrees	
Needle height		5 degrees	
Main shaft timing	L	LED2 light out at 0 degrees	
	С	LED1 light on at 265-282 degrees	
Carriage	х	200g	
Carriage	Y	200g	
Timing belt		-	
Motor belt		320 – 330 g	

You can use TAJIMA made tubular fame which has the same installation width (space between left and right positioning pin) as HAPPY's frame by changing the position of both left and right hold springs and left and right hold spring bases. Follow the procedure below after removing tubular frame.

- 1. Loosen screws (2 each at both left and right).
- 2. Move both left and right hold spring bases deep into screws.
- Move both left and right hold springs forward until the spring touches screws and stops moving.
- 4. Tighten screws (2 each at both left and right).
- Install tubular frame and check if the tip of both left and right hold springs enters receiving hole on tubular frame.

If the tip dose not enter receiving hole, loosen screw, rotate hold springs left or right so that the tip can enter the hole, and tighten screw.

Please reverse the procedure above when returning to the position of something before change has been made.





2019 / 12

HappyJapan Inc.

9-5. TAITO 2-CHOME,TAITO-KU,TOKYO,JAPAN TEL +81-3-3834-0711 FAX +81-3-3835-8917